

marka	AUTO	Model	ABS	4WD	Engine	Type of fuel	CC	YEAR	JD	HDK	OEM	сторона (R/L)	Наименование
ALFA ROMEO													
Alfa Romeo	Alfa Romeo 166	936			841C000	Diesel	2.4L	02-	JCT0121		60815163	R/L	внешний
AUDI													
Audi	A2 (8Z0) 1.4				AUA/ BBY	Petrol	1.4L	00-	JCT0108		6Q0498099	R/L	внешний
Audi	A3 II (8P1), Sportback				BGU/ BSE/ BSF/ CCSA/ CMXA	Petrol	1.6L	5/03-	JCT0096		1K0407311G/1K0498099A	R/L	внешний
Audi	A3 II (8P1), Sportback FSI				BAG/ BLE/ BLP	Petrol	1.6L	5/03-	JCT0096		1K0407311G/1K0498099A	R/L	внешний
Audi	A4 Avant	8D2, B5	да		AKN	Diesel	2.5L TDi	97-00	JCT0163A		4D0498099	R/L	внешний
Audi	A4 I (8D2, B5), Avant		да		ALZ	Petrol	1.6L	00-	JCT0088A		3B0498099/3B0498099A/3B0498099D/8D0407305Q	R/L	внешний
Audi	A4 I (8D2, B5), Avant		да		APT/ ARG/ AVV	Petrol	1.8L	95-01	JCT0088A		3B0498099/3B0498099A/3B0498099D/8D0407305Q	R/L	внешний
Audi	A4 I (8D2, B5), Avant Quattro		да		APT/ ARG/ AVV	Petrol	1.8L	95-01	JCT0088A		3B0498099/3B0498099A/3B0498099D/8D0407305Q	R/L	внешний
Audi	A4 I (8D2, B5), Avant Quattro		да		ADR	Petrol	1.8L	95-01	JCT0088A		3B0498099/3B0498099A/3B0498099D/8D0407305Q	R/L	внешний
Audi	A4 I (8D2, B5), Avant TDi Quattro		да		AFN/ AVG	Diesel	1.9L	95-	JCT0088A		3B0498099/3B0498099A/3B0498099D/8D0407305Q	R/L	внешний
Audi	A4 I (8D2, B5), Avant TDi Quattro		да		AIM/ ATJ	Diesel	1.9L	00-01	JCT0088A		3B0498099/3B0498099A/3B0498099D/8D0407305Q	R/L	внешний
Audi	100 III Avant Quattro, Kat	44, 44Q, C3			KU		2.2L	84-12	JCN0110		431498103C	R/L	внешний
Audi	80 I	80, 81, B1			ZA		1.3L	72-78	JCN0134		113501331	R/L	внешний
Audi	80 I	80, 81, B1			ZF		1.3L	72-78	JCN0134		113598101	R/L	внешний
Audi	80 III	89, 89Q, 8A, B3			6A		2.0L	90-91	JCT0126		893407311D	R/L	внешний
Audi	80 III	89, 89Q, 8A, B3	да		RA/ SB	Diesel	1.6L TD	86-91	JCT0136A		893407305N	R/L	внешний
Audi	80 IV Avant	8C, B4			ACE		2.0L	92-96	JCT0101		893498099G	R/L	внешний
Audi	80 IV Avant	8C, B4			ACE		2.0L E	92-94	JCN0110		251598101A	R/L	внешний
Audi	80 IV Avant	8C, B4	да		ADA		1.6L E	91-94	JCT0136A		893498099M	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			ACE		2.0L	92-	JCN0134		171407331F	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			ACE		2.0L	92-96	JCN0133		191407331	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			ABC		2.6L	92-96	JCN0133		191407331A	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			AAH		2.8L	91-96	JCN0133		1H0407331D	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			ABK		2.0L	91-94	JCN0133		321407331D	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			NG		2.3L E	91-96	JCN0133		321498103B	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			NG		2.3L E	91-96	JCN0133		811498103A	R/L	внешний
Audi	80 IV Avant Quattro	8C, B4			NG		2.3L E	91-96	JCN0133		893498103	R/L	внешний
Audi	90 II	89, 89Q, 8A, B3			NG		2.3L E	87-91	JCT0101		895498099B	R/L	внешний
Audi	90 II	89, 89Q, 8A, B3			KV		2.2L E	87-91	JCT0101		895407305	R/L	внешний
Audi	90 II	89, 89Q, 8A, B3			KV		2.2L E	87-91	JCT0126		893498099B	R/L	внешний
Audi	90 II	89, 89Q, 8A, B3			KV		2.2L E	87-91	JCT0126		893498099F	R/L	внешний
Audi	90 II	89, 89Q, 8A, B3			KV		2.2L E	87-91	JCT0126		893498099H	R/L	внешний
Audi	90 II	89, 89Q, 8A, B3	да		NG		2.3L E	87-91	JCT0136A		895407305B	R/L	внешний
Audi	90 II Quattro	89, 89Q, 8A, B3	да		NG		2.3L E	87-91	JCT0136A		895498099A	R/L	внешний
Audi	90 II Quattro	89, 89Q, 8A, B3	да		NG		2.3L E	87-91	JCT0136A		895498099H	R/L	внешний
Audi	90 II Quattro	89, 89Q, 8A, B3	да		NG		2.3L E	87-91	JCT0136A		8A0498099	R/L	внешний
Audi	A2	8Z0			AMF/ BHC	Diesel	1.4L TDi	00-	JCT0158		6Q0498099E	R/L	внешний
Audi	A3 I Quattro	8L1			AGN/ APG		1.8L	96-	JCN0159		191498104	R/L	внешний
Audi	A4 Avant	8D2, B5	да		AFB	Diesel	2.5L TDi	97-00	JCT0163A		4D0598099	R/L	внешний
Audi	A4 Avant		да				1.6L	95/01-00/07	JCT0081A	VW01A45	8D0407305G	R/L	внешний
Audi	A4 Avant		да				1.8L	95/01-01/09	JCT0081A	VW01A45	8D0498099	R/L	внешний
Audi	A4 I Avant	8D2, B5			AFY		1.8L	95-01	JCN0110		443407331D	R/L	внешний
Audi	A4 I Avant	8D2, B5			APT/ ARG/ AVV		1.8L	95-01	JCN0110		443498103A	R/L	внешний
Audi	A4 I Avant (Exc. Avant)	8D2, B5			ADR		1.8L	95-01	JCN0110		431407331G	R/L	внешний
Audi	A4 I Avant Quattro	8D2, B5			ADR		1.8L	95-01	JCN0110		431407331G	R/L	внешний
Audi	A4 I Avant Quattro	8D2, B5			AEB/ ANB/ APU/ ARK		1.8L	95-01	JCN0160		191498103	R/L	внешний
Audi	A4 I Avant Quattro	8D2, B5			AWT		1.8L	95-01	JCN0160		191498103A	R/L	внешний
Audi	A4 II Avant	8E2, B6	да		ALZ		1.6L	00-	JCT0093A		8E0407305A	R/L	внешний
Audi	A4 II Avant , Quattro	8E2, B6	да		AVJ		1.8L	00-	JCT0093A		8E0407305D	R/L	внешний
Audi	A4 II Avant , Quattro	8E2, B6	да		BFB		1.8L	02-	JCT0093A		8E0498099	R/L	внешний
Audi	A4 II Avant , Quattro	8E2, B6	да		BEX		1.8L	02-04	JCT0093A		8E0498099D	R/L	внешний
Audi	A6		да				1.8L	97-05	JCT0081A	VW01A45	8D0498099B	R/L	внешний
Audi	A6 Avant III	4F2			BPJ		2.0L TFSI	05-	JCT0143		4F0498099A	R/L	внешний
Audi	A6 I Avant	4A, C4			AAE		2.0L	94-97	JCN0110		431407311G	R/L	внешний
Audi	A6 I Avant	4A, C4			ABK		2.0L	94-97	JCN0110		431407331G	R/L	внешний
Audi	A6 I Avant Quattro	4A, C4			ABC		2.6L	94-97	JCN0102		431407331H	R/L	внешний
Audi	A6 I Avant Quattro	4A, C4			ACE		2.0L	94-97	JCN0102		443498103	R/L	внешний
Audi	A6 II Avant	4B, C5	да		AGA/ ALP/ AML/ APS/ ARJ		2.4L	97-01	JCT0163A		8D0407305J	R/L	внешний
Audi	A8 I Quattro	4D2, 4D8	да		AAH		2.8L	94-	JCT0163A		4D0498099	R/L	внешний
Audi	A8 II Quattro	4E			BPK		3.2 FSI	05-	JCT0143		4F0498099A	R/L	внешний
Audi	V8 Quattro	D1			PT		3.6L	88-11	JCN0110		431498103C	R/L	внешний
BMW													
BMW	X5 I	E53			M54306S3		3.0L i	00-06	JCT0094		31607505005	R/L	внешний
BMW	X5 I	E53			N62B44A		4.4L i	03-06	JCT0094		31607505006	R/L	внешний
BMW	3 (E 30) 325 i							87-93	JCN0111			R/L	внутренний
BMW	3 (E 30) 325 i							85-87	JCN0111			R/L	внутренний
BMW	3 (E30) 324 td							87-91	JCN0111			R/L	внутренний
BMW	3 (E30) 325 i							86-91	JCN0111			R/L	внутренний
BMW	3 (E30) 325 i							83-89	JCN0111			R/L	внутренний
BMW	3 (E30) M3 2.3						2.3L	86-91	JCN0111			R/L	внутренний
BMW	3 (E30) M3 2.3						2.3L	87-89	JCN0111			R/L	внутренний
BMW	3 (E30) M3 2.3						2.3L	89-91	JCN0111			R/L	внутренний
BMW	3 Touring (E30) 316 i							91-94	JCN0111			R/L	внутренний
BMW	3 Touring (E30) 316 i							91-94	JCN0111			R/L	внутренний
BMW	3 Touring (E30) 318 i							89-94	JCN0111			R/L	внутренний
BMW	3 Touring (E30) 318 i							87-91	JCN0111			R/L	внутренний
BMW	3 Touring (E30) 320 i							88-91	JCN0111			R/L	внутренний
BMW	3 Touring (E30) 324 td							88-93	JCN0111			R/L	внутренний

BMW	3 Touring (E30) 325 i							87-93	JCN0111				R/L	внутренний
BMW	5 (E 34) 518 i							89-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 518 i							89-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 520 i							88-91	JCN0111				R/L	внутренний
BMW	5 (E 34) 520 i 24V							89-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 524 id							88-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 525 i							88-91	JCN0111				R/L	внутренний
BMW	5 (E 34) 525 i 24V							89-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 525 iX 24V							91-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 525 id							93-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 525 ids							91-95	JCN0111				R/L	внутренний
BMW	5 (E 34) 530 i V8							92-95	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 518 g							95-96	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 518 i							93-94	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 518 i							94-97	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 520 i							91-97	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 525 i							91-97	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 525 iT							91-97	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 525 ix							92-97	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 525 id							93-97	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 525 ids							91-97	JCN0111				R/L	внутренний
BMW	5 Touring (E34) 530 i V8							92-97	JCN0111				R/L	внутренний
CHRYSLER														
Chrysler	Voyager III	RG	да			EDZ		2.4L	00-	JCT0095A			R/L	внешний
Chrysler	Voyager III	RG	да			ENC/ ENJ	Diesel	2.5L CRD	00-	JCT0095A			R/L	внешний
CITROEN														
Citroen	C3 I	FC				8HX(DV4TD)	Diesel	1.4L HDi	02-	JCT0118		3272EN	L	внешний
Citroen	C3 I Van					8HX(DV4TD)	Diesel	1.4L HDi	02-	JCT0118		3272ES	L	внешний
DACIA														
Dacia	Logan I, MCV 1.4					K7J710	Petrol	1.4L	04-01-07	JCA0083		6001548102/ 8200444438	L	Вал привоной
Dacia	Logan I, MCV 1.4					K7J710	Petrol	1.4L	04-01-07	JCA0084		6001548103/ 8200484373	R	Вал привоной
Dacia	Logan I, MCV 1.6					K7M710	Petrol	1.6L	04-01-07	JCA0083		6001548102/ 8200444438	L	Вал привоной
Dacia	Logan I, MCV 1.6					K7M710	Petrol	1.6L	04-01-07	JCA0084		6001548103/ 8200484373	R	Вал привоной
Dacia	Sandero I, Stepway 1.2					D4F732	Petrol	1.2L	09-	JCA0083		6001548102/ 8200444438	L	Вал привоной
Dacia	Sandero I, Stepway 1.2					D4F732	Petrol	1.2L	09-	JCA0084		6001548103/ 8200484373	R	Вал привоной
Dacia	Sandero I, Stepway 1.4					K7J714	Bi-Fuel	1.4L	09-	JCA0083		6001548102/ 8200444438	L	Вал привоной
Dacia	Sandero I, Stepway 1.4					K7J714	Bi-Fuel	1.4L	09-	JCA0084		6001548103/ 8200484373	R	Вал привоной
Dacia	Sandero I, Stepway 1.6					K7M710	Petrol	1.6L	09-	JCA0083		6001548102/ 8200444438	L	Вал привоной
Dacia	Sandero I, Stepway 1.6					K7M710	Petrol	1.6L	09-	JCA0084		6001548103/ 8200484373	R	Вал привоной
Dacia	Sandero I, Stepway 1.5 dCi					K9K792	Diesel	1.5L	09-	JCA0083		6001548102/ 8200444438	L	Вал привоной
Dacia	Sandero I, Stepway 1.5 dCi					K9K792	Diesel	1.5L	09-	JCA0084		6001548103/ 8200484373	R	Вал привоной
DAEWOO														
Daewoo	Ceilo Racer	ETI				GTI		1.5L	92/01	JCT0085	DW02	96251136	R	внешний
Daewoo	Ceilo Racer	ETI				GTI		1.5L	92/01	JCT0085	DW02	96251135	L	внешний
Daewoo	Ceilo Racer	ETI				GTI		1.5L	92/01	JCT0085	DW02	510734	R/L	внешний
Daewoo	Ceilo Racer	GS				VAN		1.5L	92/01	JCT0085	DW02	96251136	R	внешний
Daewoo	Ceilo Racer	GS				VAN		1.5L	92/01	JCT0085	DW02	96251135	L	внешний
Daewoo	Ceilo Racer	GS				VAN		1.5L	92/01	JCT0085	DW02	510734	R/L	внешний
Daewoo	Ceilo Racer	GL				GLE		1.6L	92/01	JCT0085	DW02	510734	R/L	внешний
Daewoo	Ceilo Racer	GL				GLE		1.6L	92/01	JCT0085	DW02	96251136	R	внешний
Daewoo	Ceilo Racer	GL				GLE		1.6L	92/01	JCT0085	DW02	96251135	L	внешний
Daewoo	Espero	KLEJ						1.5L	93-94	JCT0087		96257802	R/L	внешний
Daewoo	Espero	KLEJ						1.5L	93-94	JCT0087		96243573	R/L	внешний
Daewoo	Lanos	KLAT				H/B		1.5L	97/01	JCT0145	DW06	96257804	R/L	внешний
Daewoo	Lanos	A14SMS	да					1.4L	97/05	JCT0086A	DW06A47	96298465	R	внешний
Daewoo	Lanos	A14SMS	да					1.4L	97/05	JCT0086A	DW06A47	96298466	L	внешний
Daewoo	Lanos		да					1.5L	95/01	JCT0086A	DW06A47	96257803	R/L	внешний
Daewoo	Lanos	A15SMS	да					1.5L	97/05	JCT0086A	DW06A47	96257803	R/L	внешний
Daewoo	Nexia					GLE/GL		1.5L	96/01	JCT0085	DW02	26010773	R	внешний
Daewoo	Nexia					GLE/GL		1.5L	96/01	JCT0085	DW02	26013813	R	внешний
Daewoo	Nexia					GLE/GL		1.5L	96/01	JCT0085	DW02	510734	R	внешний
Daewoo	Nexia					GLE/GL		1.5L	96/01	JCT0085	DW02	96160618A	R	внешний
Daewoo	Tico	KLY3				F8C		0.8L	95-	JCT0157		4410578B00000	R/L	внешний
DAIHATSU														
Daihatsu	Storia Sirion	M100				EJ-DE		1.0L	98/01	JCT0002	DA14	4341097201	R/L	внешний
Daihatsu	Storia Sirion	M100				EJ-DE		1.0L	98/01	JCT0002	DA14	4342097201	R/L	внешний
Daihatsu	Storia Sirion	M110			4WD	EJ-DE		1.0L	98/01	JCT0002	DA14	4341097202	R	внешний
Daihatsu	Storia Sirion	M110			4WD	EJ-DE		1.0L	98/01	JCT0002	DA14	4342097201	R	внешний
Daihatsu	Storia Sirion	M100S				EJ-DE		1.0L	98-00	JCT0002	DA14	4341097201	R	внешний
Daihatsu	Storia Sirion	M100S				EJ-DE		1.0L	98-00	JCT0002	DA14	4342097208	L	внешний
Daihatsu	Terios	J100	да			HC-JE		1.3L	97/03	JCT0001A	DA12A48	4341087402	R/L	внешний
Daihatsu	Terios	J100	да			HC-JE		1.3L	97/03	JCT0001A	DA12A48	4342087402	R/L	внешний
FIAT														
Fiat	Brava	182				182A5000		1.4L	95-	JCT0138		7659169	R/L	внешний
Fiat	Brava	182				182A3000		1.4L	95-	JCT0138		92601903	R/L	внешний
Fiat	Brava	182				182A6000		1.6L	95-	JCT0138		7659169	R/L	внешний
Fiat	Brava	182				160A7000	Diesel	1.9L D	95-	JCT0138			R/L	внешний
Fiat	Croma	194				939A2000	Diesel	1.9L	05-	JCT0131		46308230	R/L	внешний
Fiat	Croma	194				939A3000	Diesel	2.4L	05-	JCT0131		46308230	R/L	внешний
Fiat	Croma	194				939A7000	Diesel	1.9L	05-	JCT0131		46308230	R/L	внешний
Fiat	Croma	194				939A1000	Diesel	1.9L	05-	JCT0131		46308230	R/L	внешний

Fiat	Idea	135			843A1000	1.4L	04-	JCT0104		46307889	R/L	внешний	
Fiat	Lancia Musa I	184			843A1000	1.4L	04-	JCT0104		46307889	R/L	внешний	
Fiat	LCV Punto Van	176L			176B7000	Diesel	1.7L TD	96-99	JCT0139	46307094	R/L	внешний	
Fiat	Punto Cabrio	176.C			176B7000	Diesel	1.7L TD	96-99	JCT0139	46307094	R/L	внешний	
Fiat	Punto I Cabrio	176.C			176A6000/176B2000		1.1L	93-99	JCT0138	92601903	R/L	внешний	
Fiat	Punto II	188			188A5000		1.2L	99-03	JCT0104	46307557	R/L	внешний	
Fiat	Punto Van II	188AX			188A4000		1.2L	00-	JCT0104	46307557	R/L	внешний	
FORD													
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.0 Di		да		D3FA	Diesel	2.0L	00-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.0 Di		да		F3FA	Diesel	2.0L	00-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.0 Di		да		ABFA	Diesel	2.0L	00-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.0 TDCi		да		F1FA	Diesel	2.0L	02-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.3 16v		да		E5FA/ C	Petrol	2.3L	01-06	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.4 Di		да		F4FA	Diesel	2.4L	00-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.4 Di		да		D2FA/ B/ E	Diesel	2.4L	00-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.4 Di		да		D4FA	Diesel	2.4L	00-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.4 TDCi		да		H9FA	Diesel	2.4L	00-	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.4 TDE		да		FXFA	Diesel	2.4L	04-06	JCT0137A	4602016	R/L	внешний	
Ford	LCV, Truck Transit VII (FA, FD, FM) 2.4 TDE		да		DOFA	Diesel	2.4L	01-	JCT0137A	4602016	R/L	внешний	
Ford	Fiesta V	JH			FYJA		1.6L	01-	JCT0112	1142788	R/L	внешний	
Ford	Focus II (Europe)							04-	JCT0080	1345638	R/L	внешний	
Ford	Focus II (Europe)							04-	JCT0080	1474807	R/L	внешний	
Ford	Focus II (Europe)							04-	JCT0080	1475135	R/L	внешний	
Ford	Focus II (Europe)				AODA/ B		2.0L	04-	JCT0128	1359663	R/L	внешний	
Ford	Focus II (Europe)				ASDA/ B		1.4L	04-	JCT0128	1437541	R/L	внешний	
Ford	Focus II (Europe)				HWDA/ B/ SHDA		1.6L	04-	JCT0128	1493015	R/L	внешний	
Ford	Focus II (Europe)				G6DA/ B/ D	Diesel	2.0L	04-	JCT0128	1359663	R/L	внешний	
Ford	Focus II (Europe)				G8DA/ B	Diesel	1.6L	04-08	JCT0128	1437541	R/L	внешний	
Ford	Focus II (Europe)				KKDA	Diesel	1.8L	04-	JCT0128	1493015	R/L	внешний	
Ford	Focus II (Europe)				HXDA		1.6L ti	04-	JCT0128	1302515	R/L	внешний	
Ford	Ford C-MAX II (Europe)				HHD/ B	Diesel	1.6L	07-	JCT0128	1302515	R/L	внешний	
Ford	Ford C-MAX II (Europe)				G8DC/ MTD/ A	Diesel	1.6L	07-	JCT0128	1359663	R/L	внешний	
Ford	Ford C-MAX II (Europe)				G8DB	Diesel	1.6L	07-	JCT0128	1437541	R/L	внешний	
Ford	Ford C-MAX II (Europe)				KKDA	Diesel	1.8L	07-	JCT0128	1493015	R/L	внешний	
Ford	Ford C-MAX II (Europe)				G8DA/ B	Diesel	1.6L	03-08	JCT0128	1302515	R/L	внешний	
Ford	Ford Fiesta V (Europe)	JH			BAJA		1.3Li	01-	JCT0127	1148219	R/L	внешний	
Ford	Ford Fiesta V (Europe)	JH			A9JA/ B		1.3L	01-	JCT0127	1148219	R/L	внешний	
Ford	Ford Fiesta V (Europe)	JH			M7JA/ B		1.2L	03-	JCT0127	1148219	R/L	внешний	
Ford	Ford Fiesta V (Europe)	JH			FXJA/ B		1.4L	01-	JCT0127	1148219	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FXDA/ B/ C/ D		1.4L	98-	JCT0097	1129668	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			BHDA/ B	Diesel	1.8 Di	99-04	JCT0097	1134142	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FYDA/ B/ C/ D		1.6L	98-	JCT0097	1361301	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FYDA/ B/ C/ D		1.6L	98-	JCT0097	1602947	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FYDA/ B/ C/ D		1.6L	98-	JCT0097	3652045	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FYDA/ B/ C/ D		1.6L	98-	JCT0097	3652047	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FYDA/ B/ C/ D		1.6L	98-	JCT0097	3667428	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FYDA/ B/ C/ D		1.6L	98-	JCT0097	3667429	R/L	внешний	
Ford	Ford Focus I (Europe)	SW			FYDA/ B/ C/ D		1.6L	98-	JCT0127	1148219	R/L	внешний	
Ford	Ford Fusion	JU			FXJA/ B/ C/ UTJA		1.4L	02-	JCT0127	1148219	R/L	внешний	
Ford	Fusion	JU			FYJA/ B		1.6L	02-08	JCT0112	1142788	R/L	внешний	
Ford	Mondeo III (Europe)	B5Y			C1BA/ B		2.0L	00-07	JCT0098	1326260	R/L	внешний	
Ford	Mondeo III (Europe)	B5Y			C1BA/ B		1.8L	00-07	JCT0098	4106369	R/L	внешний	
Ford	Mondeo III (Europe)	B5Y			CHBA/ B		1.8L	00-07	JCT0098	1326260	R/L	внешний	
Ford	Mondeo III (Europe)	B5Y			CFBA		1.8L	00-07	JCT0098	4106369	R/L	внешний	
HONDA													
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4950	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4952	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44306SM4952	L	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4953	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4954	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44306SM4953	L	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44306SM4954	L	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4J80	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4J81	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44306SM4J80	L	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44306SM4J81	L	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4J83	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44305SM4J84	R	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44306SM4J83	L	внешний
Honda	Accord	CB1	да		F18A		1.8L	89-93	JCT0007A	HO22A50	44306SM4J84	L	внешний
Honda	Accord	CD3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44305SM4953	R	внешний
Honda	Accord	CD3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44305SM4954	R	внешний
Honda	Accord	CD3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44306SM4953	L	внешний
Honda	Accord	CD3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44306SM4954	L	внешний
Honda	Accord	CB3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44305SM4J80	R	внешний
Honda	Accord	CB3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44305SM4J81	R	внешний
Honda	Accord	CB3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44306SM4J80	L	внешний
Honda	Accord	CB3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44306SM4J81	L	внешний
Honda	Accord	CB3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44305SM4J83	R	внешний
Honda	Accord	CB3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44305SM4J84	R	внешний
Honda	Accord	CB3	да		F20A		2.0L	89-93	JCT0007A	HO22A50	44306SM4J83	L	внешний

Honda	Civic	EK4	да		B16A	1.6L	95-00	JCT0008A	HO24A50	44010804J51	R	внешний
Honda	Civic	EK4	да		B16A	1.6L	95-00	JCT0008A	HO24A50	44011504J51	L	внешний
Honda	Civic	EK4	да		B16A	1.6L	95-00	JCT0006A	HO21A50	44010804J51	R	внешний
Honda	Civic	EK4	да		B16A	1.6L	95-00	JCT0006A	HO21A50	44011504J51	L	внешний
Honda	Civic	EK5	да	4WD	D16A	1.6L	95-00	JCT0006A	HO21A50	44010807950	R	внешний
Honda	Civic	EK5	да	4WD	D16A	1.6L	95-00	JCT0006A	HO21A50	44011507950	L	внешний
Honda	Civic	U2	да	4WD	D15B	1.5L	00-09	JCT0011A	HO055A50	4430555CN50/1	R	внешний
Honda	Civic	EU3	да		D17A	1.7L	00-09	JCT0011A	HO055A50	4430555AJ60/1	R	внешний
Honda	Civic	EU4	да	4WD	D17A	1.7L	00-09	JCT0011A	HO055A50	4430555CN50/1	R	внешний
Honda	Civic		да		K20	2.0L	03.01-05.12	JCT0011A	HO055A50	44014SDZT00	R	внешний
Honda	Civic	U2	да	4WD	D15B	1.5L	00-09	JCT0011A	HO055A50	4430655C951/2	L	внешний
Honda	Civic	EU3	да		D17A	1.7L	00-09	JCT0011A	HO055A50	4430655AJ61/2	L	внешний
Honda	Civic	EU4	да	4WD	D17A	1.7L	00-09	JCT0011A	HO055A50	4430655C951/2	L	внешний
Honda	Civic		да		K20	2.0L	03.01-05.12	JCT0011A	HO055A50	44014SDZT00	L	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00/09	JCT0011A	HO55A50	4430555C950	R	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00/09	JCT0011A	HO55A50	4430655C952	L	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00/09	JCT0011A	HO55A50	4430555CN50	R	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00/09	JCT0011A	HO55A50	4430555CN51	R	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00/09	JCT0011A	HO55A50	4430655C951	L	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00/09	JCT0011A	HO55A50	4430555AJ50	R	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00/09	JCT0011A	HO55A50	4430655AJ51	L	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00/09	JCT0011A	HO55A50	4430555AJ60	R	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00/09	JCT0011A	HO55A50	4430555AJ61	R	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00/09	JCT0011A	HO55A50	4430655AJ61	L	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00/09	JCT0011A	HO55A50	4430655AJ62	L	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00-09	JCT0011A	HO055A50	4430555C950	R	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00-09	JCT0011A	HO055A50	4430555CN50/1	R	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00-09	JCT0011A	HO055A50	4430555AJ50	R	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00-09	JCT0011A	HO055A50	4430555AJ60/1	R	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00-09	JCT0011A	HO055A50	4430655C952	L	внешний
Honda	Civic Ferio	ES2	да	4WD	D15B	1.5L	00-09	JCT0011A	HO055A50	4430655C951/2	L	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00-09	JCT0011A	HO055A50	4430655AJ51	L	внешний
Honda	Civic Ferio	ES3	да		D17A	1.7L	00-09	JCT0011A	HO055A50	4430655AJ61/2	L	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	95-01	JCT0008A	HO24A50	44010810951	R	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	95-01	JCT0008A	HO24A50	44011510951	L	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	97-98	JCT0008A	HO24A50	44010810951	R	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	97-98	JCT0008A	HO24A50	44011510951	L	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	97-98	JCT0009A	HO33A50	44010810A60	R	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	97-98	JCT0009A	HO33A50	44011510A50	L	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	98-01	JCT0009A	HO33A50	44305510C61	R	внешний
Honda	CR-V	RD1	да	4WD	B20B	2.0L	98-01	JCT0009A	HO33A50	44306510C51	L	внешний
Honda	CR-V	RD4			K20A	2.0L	01/09	JCT0012	HO57	4430559AN00	R	внешний
Honda	CR-V	RD4			K20A	2.0L	01/09	JCT0012	HO57	4430659AN00	L	внешний
Honda	CR-V	RD5	да	4WD	K20A	2.0L	01/09	JCT0012	HO57	4430559AN00	R	внешний
Honda	CR-V	RD5	да	4WD	K20A	2.0L	01/09	JCT0012	HO57	4430659AN00	L	внешний
Honda	Domani	MA5	да		B18B	1.8L	92-97	JCT0006A	HO21A50	440108R3J55	R	внешний
Honda	Domani	MA5	да		B18B	1.8L	92-97	JCT0006A	HO21A50	440115R3J54	L	внешний
Honda	Domani	MA5	да		B18B	1.8L	92-97	JCT0006A	HO21A50	440108T7N50	R	внешний
Honda	Domani	MA5	да		B18B	1.8L	92-97	JCT0006A	HO21A50	440115T7N50	L	внешний
Honda	Civic IV	EG,EG4			D15Z1	1.5L	92-95	JCT0119			R/L	внешний
Honda	Civic VI Hatchback	EU,EP	да		D14Z6	1.4L	01-	JCT0123A		44014S6DE01	R/L	внешний
Honda	Civic VI Hatchback Sport	EU,EP	да		K20A3	2.0L		JCT0123A		44014S6DE01	R/L	внешний
Honda	HR-V	GH1	да		D16A	1.6L	98-09	JCT0011A	HO055A50	4430552H950	R	внешний
Honda	HR-V	GH1	да		D16A	1.6L	98-09	JCT0011A	HO055A50	4430552HN50	R	внешний
Honda	HR-V	GH1	да		D16A	1.6L	99-07	JCT0011A	HO055A50	4430552H950	R	внешний
Honda	HR-V	GH1	да		D16A	1.6L	99-07	JCT0011A	HO055A50	4430552H951	R	внешний
Honda	HR-V	GH2	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430552H950	R	внешний
Honda	HR-V	GH2	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430552H951	R	внешний
Honda	HR-V	GH2	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430552H950	R	внешний
Honda	HR-V	GH3	да		D16A	1.6L	99-07	JCT0011A	HO055A50	4430552H951	R	внешний
Honda	HR-V	GH4	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430552H951	R	внешний
Honda	HR-V	GH1	да		D16A	1.6L	98-09	JCT0011A	HO055A50	4430652H950	L	внешний
Honda	HR-V	GH1	да		D16A	1.6L	98-09	JCT0011A	HO055A50	4430652H950	L	внешний
Honda	HR-V	GH1	да		D16A	1.6L	99-07	JCT0011A	HO055A50	4430652H950	L	внешний
Honda	HR-V	GH1	да		D16A	1.6L	99-07	JCT0011A	HO055A50	4430652H951	L	внешний
Honda	HR-V	GH2	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430652H950	L	внешний
Honda	HR-V	GH2	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430652H951	L	внешний
Honda	HR-V	GH2	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430652H950	L	внешний
Honda	HR-V	GH3	да		D16A	1.6L	99-07	JCT0011A	HO055A50	4430652H951	L	внешний
Honda	HR-V	GH4	да	4WD	D16A	1.6L	99-07	JCT0011A	HO055A50	4430652H951	L	внешний
Honda	Inspire	UA1	да		G20A	2.0L	95-98	JCT0009A	HO33A50	440108W5950	R	внешний
Honda	Inspire	UA1	да		G20A	2.0L	95-98	JCT0009A	HO33A50	440115W5950	L	внешний
Honda	Inspire	UA2	да		G25A	2.5L	95-98	JCT0009A	HO33A50	440108W5950	R	внешний
Honda	Inspire	UA2	да		G25A	2.5L	95-98	JCT0009A	HO33A50	440115W5950	L	внешний
Honda	Inspire	CB5	да		G20A	2.0L	89-95	JCT0007A	HO22A50	440108L4952	R	внешний
Honda	Inspire	CB5	да		G20A	2.0L	89-95	JCT0007A	HO22A50	440115L4952	L	внешний
Honda	Inspire	CC3	да		G20A	2.0L	92-95	JCT0007A	HO22A50	440108L5N82	R	внешний
Honda	Inspire	CC3	да		G20A	2.0L	92-95	JCT0007A	HO22A50	440115L5N80	L	внешний
Honda	Integra	DB6	да		ZC	1.6L	93-95	JCT0008A	HO24A50	440108T7950	R	внешний
Honda	Integra	DB6	да		ZC	1.6L	93-95	JCT0008A	HO24A50	440115T7950	L	внешний
Honda	Integra	DC1	да		ZC	1.6L	93-95	JCT0008A	HO24A50	440108T7950	R	внешний

Honda	Stream		RN2	да	4WD	D17A		1.7L	00.11-	JCT0011A	HO055A50		4430555CN51	R	внешний
Honda	Stream		RN3	да		K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4430557C950	R	внешний
Honda	Stream		RN3	да		K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4401457C950	R	внешний
Honda	Stream		RN3	да		K20A		2.0L	00.10-	JCT0011A	HO055A50		4401456M950	R	внешний
Honda	Stream		RN3	да		K20A		2.0L	00.11-	JCT0011A	HO055A50		4430557C950	R	внешний
Honda	Stream		RN4	да	4WD	K20A		2.0L	00.11-	JCT0011A	HO055A50		4430557C950	R	внешний
Honda	Stream		RN4	да	4WD	K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4430557C950	R	внешний
Honda	Stream		RN4	да	4WD	K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4401457C950	R	внешний
Honda	Stream		RN5	да		K20B		2.0L	04.01-06.07	JCT0011A	HO055A50		4430557C950	R	внешний
Honda	Stream		RN5	да		K20B		2.0L	04.01-06.07	JCT0011A	HO055A50		4401457C950	R	внешний
Honda	Stream		RN5	да		K20B		2.0L	03.12-	JCT0011A	HO055A50		4430557C950	R	внешний
Honda	Torneo		CF3	да		F18B SOHC		1.8L	97.09-02.10	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Torneo		CF4	да		F20B SOHC		2.0L	97.09-00.05	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Torneo		CF4	да		F20B SOHC		2.0L	99.07-00.05	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Torneo		CF4	да		F20B DOHC		2.0L	97.09-02.10	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Torneo		CF4	да		F20B DOHC		2.0L	01.05-02.10	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Torneo		CF5	да	4WD	F20B SOHC		2.0L	97.09-02.10	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Torneo		CL3	да		F20B SOHC		2.0L	00.06-02.10	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Torneo		CL3	да		F20B SOHC		2.0L	00.06-02.10	JCT0011A	HO055A50		4430550A960	R	внешний
Honda	Stream		RN1	да		D17A		1.7L	00.11-	JCT0011A	HO055A50		4430655AJ62	L	внешний
Honda	Stream		RN1	да		D17A		1.7L	00.10-	JCT0011A	HO055A50		4401457AJ50	L	внешний
Honda	Stream		RN1	да		D17A		1.7L	00.10-	JCT0011A	HO055A50		4401455AJ52	L	внешний
Honda	Stream		RN1	да		D17A		1.7L	06.07-	JCT0011A	HO055A50		4430655AJ62	L	внешний
Honda	Stream		RN1	да		D17A		1.7L	06.07-	JCT0011A	HO055A50		4401457AJ50	L	внешний
Honda	Stream		RN1	да		D17A		1.7L	06.07-	JCT0011A	HO055A50		4401455AJ53	L	внешний
Honda	Stream		RN2	да	4WD	D17A		1.7L	04.01-06.07	JCT0011A	HO055A50		4430655C952	L	внешний
Honda	Stream		RN2	да	4WD	D17A		1.7L	04.01-06.07	JCT0011A	HO055A50		4401456M950	L	внешний
Honda	Stream		RN2	да	4WD	D17A		1.7L	00.11-	JCT0011A	HO055A50		4430657B950	L	внешний
Honda	Stream		RN2	да	4WD	D17A		1.7L	00.11-	JCT0011A	HO055A50		4430655C952	L	внешний
Honda	Stream		RN3	да		K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4430657C950	L	внешний
Honda	Stream		RN3	да		K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4401457C950	L	внешний
Honda	Stream		RN3	да		K20A		2.0L	00.10-	JCT0011A	HO055A50		4401456M950	L	внешний
Honda	Stream		RN3	да		K20A		2.0L	00.11-	JCT0011A	HO055A50		4430657C950	L	внешний
Honda	Stream		RN4	да	4WD	K20A		2.0L	00.11-	JCT0011A	HO055A50		4430657C950	L	внешний
Honda	Stream		RN4	да	4WD	K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4430657C950	L	внешний
Honda	Stream		RN4	да	4WD	K20A		2.0L	04.01-06.07	JCT0011A	HO055A50		4401457C950	L	внешний
Honda	Stream		RN5	да		K20B		2.0L	04.01-06.07	JCT0011A	HO055A50		4430657C950	L	внешний
Honda	Stream		RN5	да		K20B		2.0L	04.01-06.07	JCT0011A	HO055A50		4401457C950	L	внешний
Honda	Stream		RN5	да		K20B		2.0L	03.12-	JCT0011A	HO055A50		4430657C950	L	внешний
Honda	Torneo		CF3	да		F18B SOHC		1.8L	97.09-02.10	JCT0011A	HO055A50		4430650A960	R	внешний
Honda	Torneo		CF4	да		F20B SOHC		2.0L	97.09-00.05	JCT0011A	HO055A50		4430650A960	L	внешний
Honda	Torneo		CF4	да		F20B SOHC		2.0L	99.07-00.05	JCT0011A	HO055A50		4430650A960	R	внешний
Honda	Torneo		CF4	да		F20B DOHC		2.0L	97.09-02.10	JCT0011A	HO055A50		4430650A960	L	внешний
Honda	Torneo		CF4	да		F20B DOHC		2.0L	01.05-02.10	JCT0011A	HO055A50		4430650A960	L	внешний
Honda	Torneo		CF5	да	4WD	F20B SOHC		2.0L	97.09-02.10	JCT0011A	HO055A50		4430650A960	L	внешний
Honda	Torneo		CL3	да		F20B SOHC		2.0L	00.06-02.10	JCT0011A	HO055A50		4430650A960	L	внешний
Honda	Torneo		CL3	да		F20B SOHC		2.0L	00.06-02.10	JCT0011A	HO055A50		4430650A960	L	внешний
HYUNDAI															
Hyundai	Elantra							1.6L		JCT0069	HY02		495002D000	R	внешний
Hyundai	Elantra							1.6L		JCT0069	HY02		495012D002	R	внешний
Hyundai	Elantra							1.6L		JCT0069	HY02		495002D002	L	внешний
Hyundai	Elantra		NU			4G32		1.6L	91-93	JCT0069	HY02		4950828B00	R	внешний
Hyundai	Elantra		NU			4G32		1.6L	91-93	JCT0069	HY02		4950728B00	L	внешний
Hyundai	Getz		TB	да				1.3L	02-09	JCT0105A			495001C260	R	внешний
Hyundai	Getz		TB	да				1.3L	02-09	JCT0105A			495001C250	L	внешний
Hyundai	Getz		TB	да				1.6L	02-09	JCT0105A			495001C260	R	внешний
Hyundai	Getz		TB	да				1.6L	02-09	JCT0105A			495001C250	L	внешний
Hyundai	Santa FE		D4EA	да		CRDi		2.0L		JCT0090A			4950025561	R	внешний
Hyundai	Santa FE		D4EA	да		CRDi		2.0L		JCT0090A			4950126410	R	внешний
Hyundai	Santa FE		D4EA	да		CRDi		2.0L	01-	JCT0090A			4950126411	L	внешний
Hyundai	Sonata			да				2.0L	01/01	JCT0120A	HY11A47			R/L	внешний
Hyundai	Sonata			да				2.0L	01/01	JCT0120A	HY11		3950738F00	R	внешний
Hyundai	Sonata			да				2.0L	01/01	JCT0120A	HY11		3950838F00	L	внешний
Hyundai	Sonata							2.0L	01-04	JCT0106	MI23		4950838E00	L	внешний
Hyundai	Sonata							2.0L	01-04	JCT0106	MI23		4950738E00	R	внешний
KIA															
Kia	Rio							1.3L	02/01	JCT0113	K08		0K30A25400	R	внешний
Kia	Rio							1.3L	02/01	JCT0113	K08		0K30A25600	L	внешний
Kia	Rio							1.3L	02/01	JCT0113	K08		0K30A22510	R	внешний
Kia	Rio							1.3L	02/01	JCT0113	K08		0K30A22610	L	внешний
Kia	Rio I		SW, DC			ASD		1.5L	00-05	JCT0089			KK38822510	R	внешний
Kia	Rio I		SW, DC			ASD		1.5L	00-05	JCT0089			KK38822610	L	внешний
Kia	Spectra		BFD					1.5L	91/01	JCT0014	K110		OK2N225400	R	внешний
Kia	Spectra		BFD					1.5L	91/01	JCT0014	K110		OK2N225600	R	внешний
Kia	Spectra		BFD					1.5L	91/01	JCT0014	K110		OK2N42540X	R	внешний
Kia	Spectra		BFD					1.5L	91/01	JCT0014	K110		OK2N42560X	L	внешний
LADA															
Lada	110					VAZ-415	Wankel	1.3L	97-	JCT0146			21082215010	R	внешний
Lada	111					2111	Petrol	1.5L	00-	JCT0146			21082215010	R	внешний
Lada	111					VAZ 2111	Petrol	1.5L	96-	JCT0146			21082215010	R	внешний
Lada	112					VAZ 2111	Petrol	1.5L	95-	JCT0146			21082215010	R	внешний

Lada	112				2111	Petrol	1.5L	00-	JCT0146			21082215010	R	внешний
Lada	110 16v				VAZ 2111/ VAZ 2112	Petrol	1.5L	00-	JCT0146			21082215010	R	внешний
Lada	110 2.0 i				C20XE	Petrol	2.0L	96-	JCT0146			21082215010	R	внешний
Lada	111 16v				VAZ 2112	Petrol	1.5L	95-	JCT0146			21082215010	R	внешний
Lada	111 16v				VAZ 2112	Petrol	1.5L	00-	JCT0146			21082215010	R	внешний
Lada	111 16v				VAZ 2112	Petrol	1.5L	95-	JCT0146			21082215010	R	внешний
Lada	Kalina (1117, 1118, 1119)				21114	Petrol	1.6L	04-	JCT0146			21082215010	R	внешний
Lada	Kalina (1117, 1118, 1119) 16v					Petrol	1.6L	04-	JCT0146			21082215010	R	внешний
Lada	Sagona				BA321081	Petrol	1.1L	86-	JCT0146			21082215010	R	внешний
Lada	Sagona					Petrol	1.3L	86-	JCT0146			21082215010	R	внешний
Lada	Sagona 1.5i					Petrol	1.5L	86-	JCT0146			21082215010	R	внешний
Lada	110				VAZ-415	Wankel	1.3L	97-	JCT0146			21082215011	L	внешний
Lada	111				2111	Petrol	1.5L	00-	JCT0146			21082215011	L	внешний
Lada	111				VAZ 2111	Petrol	1.5L	96-	JCT0146			21082215011	L	внешний
Lada	112				VAZ 2111	Petrol	1.5L	95-	JCT0146			21082215011	L	внешний
Lada	112				2111	Petrol	1.5L	00-	JCT0146			21082215011	L	внешний
Lada	110 16v				VAZ 2111/ VAZ 2112	Petrol	1.5L	00-	JCT0146			21082215011	L	внешний
Lada	110 2.0 i				C20XE	Petrol	2.0L	96-	JCT0146			21082215011	L	внешний
Lada	111 16v				VAZ 2112	Petrol	1.5L	95-	JCT0146			21082215011	L	внешний
Lada	111 16v				VAZ 2112	Petrol	1.5L	00-	JCT0146			21082215011	L	внешний
Lada	111 16v				VAZ 2112	Petrol	1.5L	95-	JCT0146			21082215011	L	внешний
Lada	Kalina (1117, 1118, 1119)				21114	Petrol	1.6L	04-	JCT0146			21082215011	L	внешний
Lada	Kalina (1117, 1118, 1119) 16v					Petrol	1.6L	04-	JCT0146			21082215011	L	внешний
Lada	Sagona				BA321081	Petrol	1.1L	86-	JCT0146			21082215011	L	внешний
Lada	Sagona					Petrol	1.3L	86-	JCT0146			21082215011	L	внешний
Lada	Sagona 1.5i					Petrol	1.5L	86-	JCT0146			21082215011	L	внешний
Lada	Samara (2108, 2109) 1.5						1.5L	96-	JCN0147				R/L	внутренний
Lada	Samara (2108, 2109) 1100						1.1L	88-94	JCN0147				R/L	внутренний
Lada	Samara (2108, 2109) 1300						1.3L	91-	JCN0147				R/L	внутренний
Lada	Samara (2108, 2109) 1300						1.3L	88-	JCN0147				R/L	внутренний
Lada	Samara (2108, 2109) 1300						1.3L	86-94	JCN0147				R/L	внутренний
Lada	Samara (2108, 2109) 1500						1.5L	91-	JCN0147				R/L	внутренний
Lada	Samara (2108, 2109) 1500						1.5L	95-	JCN0147				R/L	внутренний
Lada	Samara (2108, 2109) 1500						1.5L	88-	JCN0147				R/L	внутренний
Lada	Samara Forma (21099) 1100						1.1L	91-	JCN0147				R/L	внутренний
Lada	Samara Forma (21099) 1300						1.3L	91-	JCN0147				R/L	внутренний
Lada	Samara Forma (21099) 1300						1.3L	90-	JCN0147				R/L	внутренний
Lada	Samara Forma (21099) 1300						1.3L	89-97	JCN0147				R/L	внутренний
Lada	Samara Forma (21099) 1500						1.5L	91-	JCN0147				R/L	внутренний
Lada	Samara Forma (21099) 1500						1.5L	91-	JCN0147				R/L	внутренний
Lada	Samara, Forma (2108, 2109)				BA321081	Petrol	1.1L	88-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA321081(KAT)	Petrol	1.1L	96-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA32108(KAT)	Petrol	1.3L	91-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				2108	Petrol	1.3L	88-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA32108	Petrol	1.3L	86-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA321083(KAT)	Petrol	1.5L	91-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA321115	Petrol	1.3L	96-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA32111	Petrol	1.5L	94-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA321083	Petrol	1.5L	88-	JCT0146			21082215010	R	внешний
Lada	Samara, Forma (2108, 2109)				BA321081	Petrol	1.1L	88-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				BA321081(KAT)	Petrol	1.1L	96-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				BA32108(KAT)	Petrol	1.3L	91-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				2108	Petrol	1.3L	88-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				BA32108	Petrol	1.3L	86-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				BA321083(KAT)	Petrol	1.5L	91-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				BA321115	Petrol	1.3L	96-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				BA32111	Petrol	1.5L	94-	JCT0146			21082215011	L	внешний
Lada	Samara, Forma (2108, 2109)				BA321083	Petrol	1.5L	88-	JCT0146			21082215011	L	внешний
MAZDA														
Mazda	121		да					93-	JCT0015A				R/L	внешний
Mazda	Atenza / Mazda 6	GCEP	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GF092550X	R	внешний
Mazda	Atenza / Mazda 6	GCEP	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GF092560X	L	внешний
Mazda	Atenza / Mazda 6	GCEP	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GP182550XA	R	внешний
Mazda	Atenza / Mazda 6	GCEP	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GF092560XB	L	внешний
Mazda	Atenza / Mazda 6	GGES	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GF092550X	R	внешний
Mazda	Atenza / Mazda 6	GGES	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GF092560X	L	внешний
Mazda	Atenza / Mazda 6	GGES	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GP182550XA	R	внешний
Mazda	Atenza / Mazda 6	GGES	да		LF-DE		2.0L	02/05	JCT0018A	MA44A44		GF092560XB	L	внешний
Mazda	Atenza / Mazda 6	GYEW	да		LF-DE		2.0L	02/06	JCT0018A	MA44A44		GF092550X	R	внешний
Mazda	Atenza / Mazda 6	GYEW	да		LF-DE		2.0L	02/06	JCT0018A	MA44A44		GF092560X	L	внешний
Mazda	Atenza / Mazda 6	GG3P	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GF092550X	R	внешний
Mazda	Atenza / Mazda 6	GG3P	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GF092560X	L	внешний
Mazda	Atenza / Mazda 6	GG3P	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GP182550XA	R	внешний
Mazda	Atenza / Mazda 6	GG3P	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GF092560XB	L	внешний
Mazda	Atenza / Mazda 6	GG3S	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GF092550X	R	внешний
Mazda	Atenza / Mazda 6	GG3S	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GF092560X	L	внешний
Mazda	Atenza / Mazda 6	GY3W	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GF092550X	R	внешний
Mazda	Atenza / Mazda 6	GY3W	да		L3-VE		2.3L	09/05	JCT0018A	MA44A44		GF092560X	L	внешний
Mazda	Atenza / Mazda 6	GY3W	да	4WD	L3-VE		2.3L	09/06	JCT0018A	MA44A44		GF092550X	R	внешний
Mazda	Atenza / Mazda 6	GY3W	да	4WD	L3-VE		2.3L	09/06	JCT0018A	MA44A44		G112560X	L	внешний
Mazda	Capella	CG2PP	да		FP		1.8L	94-97	JCT0017A	MA018A44		G0372550X	R	внешний

Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G0372560X	L	внешний
Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G5682550XA	R	внешний
Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G5682560XA	L	внешний
Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G0472550X	R	внешний
Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G0472560X	L	внешний
Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G0472550XA	R	внешний
Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G04722510A	R/L	внешний
Mazda	Capella	CG2PP	да			FP	1.8L	94-97	JCT0017A	MA018A44		G03722510	R/L	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G0372550X	R	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G0372560X	L	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G5682550XA	R	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G5682560XA	L	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G0472550X	R	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G0472560X	L	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G0472550XA	R	внешний
Mazda	Capella	CG2SP	да			FS	2.0L	94-97	JCT0017A	MA018A44		G0472560XB	L	внешний
Mazda	Capella / 626	GD6P				B6	1.6L	87-91	JCT0070	MA05		G01325500A	R	внешний
Mazda	Capella / 626	GD6P				B6	1.6L	87-91	JCT0070	MA05		G01325600C	L	внешний
Mazda	Capella / 626	GD6P				B6	1.6L	87-91	JCT0070	MA05		G01325500	R	внешний
Mazda	Capella / 626	GD6P				B6	1.6L	87-91	JCT0070	MA05		G01325600	L	внешний
Mazda	Capella / 627	GD8PS				F8	1.8L	87-91	JCT0070	MA05		G01325500A	R	внешний
Mazda	Capella / 627	GD8PS				F8	1.8L	87-91	JCT0070	MA05		G01325600C	L	внешний
Mazda	Cronos	GERP	да			K8	1.8L	91-94	JCT0017A	MA018A44		G5682550X	R	внешний
Mazda	Cronos	GERP	да			K8	1.8L	91-94	JCT0017A	MA018A44		G5682560X	L	внешний
Mazda	Cronos	GERP	да			K8	1.8L	91-94	JCT0017A	MA018A44		G5602550X	R	внешний
Mazda	Cronos	GERP	да			K8	1.8L	91-94	JCT0017A	MA018A44		G5602560X	L	внешний
Mazda	Demio collection		да				1.4L		JCT0015A				R/L	внешний
Mazda	Demio comfort		да				1.4L		JCT0015A				R/L	внешний
Mazda	Demio exclusive		да				1.5L		JCT0015A				R/L	внешний
Mazda	Demio sportive		да				1.5L	98-	JCT0015A				R/L	внешний
Mazda	Familia VAN/WAGON Laser VAN	BJSW	да			FP	1.8L	98.06-00.10	JCT0016A	MA-034A44		FD552550X	R	внешний
Mazda	Familia VAN/WAGON Laser VAN	BJSW	да			FP	1.8L	98.06-00.10	JCT0016A	MA-034A44		FD552550X	R	внешний
Mazda	Ixion	CPSWF	да	4WD		FP-DE	1.8L	99.04-04.12	JCT0016A	MA-034A44		FD552550XA	R	внешний
Mazda	Laser Lidea Wagon	BJSWF	да			FP	1.8L	98.12-00.12	JCT0016A	MA-034A44		FD552550XA	R	внешний
Mazda	Laser Lidea Wagon	BJSWF	да			FP	1.8L	98.12-00.12	JCT0016A	MA-034A44		FD552550XA	R	внешний
Mazda	Familia VAN/WAGON Laser VAN	BJSW	да			FP	1.8L	98.06-00.10	JCT0016A	MA-034A44		FD542560X	L	внешний
Mazda	Familia VAN/WAGON Laser VAN	BJSW	да			FP	1.8L	98.06-00.10	JCT0016A	MA-034A44		FD552560X	L	внешний
Mazda	Ixion	CPSWF	да	4WD		FP-DE	1.8L	99.04-04.12	JCT0016A	MA-034A44		FD552560XA	L	внешний
Mazda	Laser Lidea Wagon	BJSWF	да			FP	1.8L	98.12-00.12	JCT0016A	MA-034A44		FD542560XA	L	внешний
Mazda	Laser Lidea Wagon	BJSWF	да			FP	1.8L	98.12-00.12	JCT0016A	MA-034A44		FD552560XA	L	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FR022550X	R	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FR022560X	L	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FG0225500C	R	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FG0225600C	L	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FG0125500D	R	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FG0125600D	L	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FR012550X	R	внешний
Mazda	Mazda 3	BKSP				ZY-VE	1.5L	03-04	JCT0071	MA34		FR012560X	L	внешний
Mazda	Mazda 3	BKEP				LF-DE	2.0L	03-04	JCT0071	MA34		GR252550XB	R	внешний
Mazda	Mazda 3	BKEP				LF-DE	2.0L	03-04	JCT0071	MA34		GR252560XB	L	внешний
Mazda	Mazda 3	BKEP				LF-DE	2.0L	03-04	JCT0071	MA34		GG2525500C	R	внешний
Mazda	Mazda 3	BKEP				LF-DE	2.0L	03-04	JCT0071	MA34		GG2525600C	L	внешний
Mazda	Mazda 3					Y601	1.6L Di T	04-09	JCT0082			GG2925500A	R/L	внешний
Mazda	Mazda 3					Y601	1.6L Di T	04-09	JCT0082			GG292550XA	R/L	внешний
Mazda	Premacy	CP8W	да	4WD		FP-DE	1.8L	99.04-04.12	JCT0016A	MA-034A44		FD552550XA	R	внешний
Mazda	Premacy	CP8W	да	4WD		FP-DE	1.8L	99.04-04.12	JCT0016A	MA-034A44		FD552550XA	R	внешний
Mazda	Premacy	CP8W	да	4WD		FP-DE	1.8L	99.04-04.12	JCT0016A	MA-034A44		FD552560XA	L	внешний
Mazda	Premacy	CP8W	да	4WD		FP-DE	1.8L	99.04-04.12	JCT0016A	MA-034A44		FD552560AC	L	внешний
Mazda	Premacy	CP8W	да			FP-DE	1.8L	99/04	JCT0019A			FA512550XA	R/L	внешний
Mazda	Premacy	CP8W	да			FP-DE	1.8L	99/04	JCT0019A			FA512560X	L	внешний
Mazda	Premacy	CP8W	да			FP-DE	1.8L	99/04	JCT0019A			FA522560XB	L	внешний
Mazda	Premacy	CP8W	да	4WD		FP-DE	1.8L	99/04	JCT0019A			FD552550XA	R	внешний
Mazda	Premacy	CP8W	да	4WD		FP-DE	1.8L	99/04	JCT0019A			FD552560XA	L	внешний
MERCEDES-BENZ														
Mercedes-Benz	Classe V 200	638/2, 638294	да			OM611980	Diesel	99-	JCT0129A			A6383342334	R/L	внешний
Mercedes-Benz	Class V 200	638/2, 638214				M111948		97-	JCN0109			A6383341734	R/L	внешний
Mercedes-Benz	Classe V 200	638/2, 638294				OM611980	Diesel	99-03	JCN0140			A6383342334	R/L	внешний
Mercedes-Benz	ClasseLASSE V 220	638/2, 638294				OM611980	Diesel	99-03	JCN0140			A6383342334	R/L	внешний
Mercedes-Benz	LCV Truck Vito 1108	638				OM611A	Diesel	2.2L CDi	99-	JCN0140		A6383342334	R/L	внешний
Mercedes-Benz	LCV Truck Vito 1110	638	да			OM611LA	Diesel	2.2L CDi	99-	JCT0129A		A6383342334	R/L	внешний
Mercedes-Benz	LCV Truck Vito 1110	638				OM611LA	Diesel	2.2L CDi	99-	JCN0140		A6383342334	R/L	внешний
Mercedes-Benz	LCV Truck Vito 1112	638				OM611980	Diesel	2.2L CDi	99-	JCN0140		A6383342334	R/L	внешний
MITSUBISHI														
Mitsubishi	Galant	EA1A				4G93	1.8L	96/08	JCT0021	MI29		MR305772	R	внешний
Mitsubishi	Galant	EA1A				4G93	1.8L	96/08	JCT0021	MI29		MR336639	L	внешний
Mitsubishi	Galant	EA1A				4G93	1.8L	96/08	JCT0021	MI29		MR305771	R	внешний
Mitsubishi	Galant	EA1A				4G93	1.8L	96/08	JCT0021	MI29		MR196750	R	внешний
Mitsubishi	Galant	EA1A				4G93	1.8L	96/08	JCT0021	MI29		MR305319	L	внешний
Mitsubishi	Lancer Cedia	CS5A	да	4WD		4G93	1.8L	00/07	JCT0022A	MI36A43		MR553010	R	внешний
Mitsubishi	Lancer Cedia	CS5A	да	4WD		4G93	1.8L	00/07	JCT0022A	MI36A43		MR553009	L	внешний
Mitsubishi	Lancer Cedia	CS2A	да	4WD		4G15	1.5L	00/07	JCT0073A	MI38A43		MR498556	R	внешний

Mitsubishi	Lancer Cedia	CS2A	да	4WD	4G15	1.5L	00/07	JCT0073A	M138A43	MR498555	L	внешний
Mitsubishi	Legnum	EA1W			4G93	1.8L	96/08	JCT0021	M129	MR305772	R	внешний
Mitsubishi	Legnum	EA1W			4G93	1.8L	96/08	JCT0021	M129	MR305771	L	внешний
Mitsubishi	Legnum	EA1W			4G93	1.8L	96/08	JCT0021	M129	MR336639	L	внешний
Mitsubishi	Legnum	EA1W			4G93	1.8L	96/08	JCT0021	M129	MR196750	R	внешний
Mitsubishi	Legnum	EA1W			4G93	1.8L	96/08	JCT0021	M129	MR305319	L	внешний
Mitsubishi	Legnum	EA1W			4G93	1.8L	96/08	JCT0021	M129	MR196749	L	внешний
Mitsubishi	Legnum	EA5W	да		6A13	2.5L	96/08	JCT0072A	M133A43	MR196758	R	внешний
Mitsubishi	Legnum	EA5W	да		6A13	2.5L	96/08	JCT0072A	M133A43	MR196757	L	внешний
Mitsubishi	Pajero	V14V			4D56	2.5L	91-93	JCT0020	M113	MB620252	R	внешний
Mitsubishi	Pajero	V14V			4D56	2.5L	91-93	JCT0020	M113	MB620253	L	внешний
Mitsubishi	Pajero	V14V			4D56	2.5L	91-93	JCT0020	M113	MB620625	L	внешний
Mitsubishi	Pajero	V14V			4D56	2.5L	91-93	JCT0020	M113	MB620251	L	внешний
Mitsubishi	Pajero	V14V			4D56	2.5L	91-93	JCT0020	M113	MB886761	L	внешний
Mitsubishi	Pajero	V24WV			4D56	2.5L	91-96	JCT0020	M113	MB620252	R	внешний
Mitsubishi	Pajero	V24WV			4D56	2.5L	91-96	JCT0020	M113	MB886761	L	внешний
Mitsubishi	Pajero	V24WV			4D56	2.5L	91-94	JCT0020	M113	MB620252	R	внешний
Mitsubishi	Pajero	V24WV			4D56	2.5L	91-94	JCT0020	M113	MB620253	L	внешний
Mitsubishi	Pajero	V24WV			4D56	2.5L	91-94	JCT0020	M113	MB620625	L	внешний
Mitsubishi	Pajero	V24WV			4D56	2.5L	91-94	JCT0020	M113	MB620251	L	внешний
Mitsubishi	Pajero	V44V			4D56	2.5L	91-93	JCT0020	M113	MB620252	R	внешний
Mitsubishi	Pajero	V44V			4D56	2.5L	91-93	JCT0020	M113	MB620253	L	внешний
Mitsubishi	Pajero	V44V			4D56	2.5L	91-93	JCT0020	M113	MB620625	R	внешний
Mitsubishi	Pajero	V44V			4D56	2.5L	91-93	JCT0020	M113	MB620251	L	внешний
Mitsubishi	Pajero	V63W	да	4WD	6G72	3.0L	02/08	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V63W	да	4WD	6G72	3.0L	02/08	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V63W	да	4WD	6G72	3.0L	02/08	JCT0074A	M445A50	MR580734	R	внешний
Mitsubishi	Pajero	V63W	да	4WD	6G72	3.0L	02/08	JCT0074A	M445A50	MR580733	L	внешний
Mitsubishi	Pajero	V73W	да	4WD	6G72	3.0L	96-02	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V73W	да	4WD	6G72	3.0L	96-02	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V73W	да	4WD	6G72	3.0L	96-02	JCT0074A	M445A50	MR580733	L	внешний
Mitsubishi	Pajero	V73W	да	4WD	6G72	3.0L	96-02	JCT0074A	M445A50	MR580734	R	внешний
Mitsubishi	Pajero	V68W	да		4M41	3.2L	99/09	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V78W	да		4M41	3.2L	99-02	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V68W	да	4WD	4M41	3.2L	99-02	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V68W	да	4WD	4M41	3.2L	99-02	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V68W	да	4WD	4M41	3.2L	02/08	JCT0074A	M445A50	MR580733	L	внешний
Mitsubishi	Pajero	V68W	да	4WD	4M41	3.2L	02/08	JCT0074A	M445A50	MR580734	R	внешний
Mitsubishi	Pajero	V78W	да	4WD	4M41	3.2L	99-02	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V78W	да	4WD	4M41	3.2L	99-02	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V78W	да	4WD	4M41	3.2L	02/08	JCT0074A	M445A50	MR580733	L	внешний
Mitsubishi	Pajero	V78W	да	4WD	4M41	3.2L	02/08	JCT0074A	M445A50	MR580734	R	внешний
Mitsubishi	Pajero	V65W	да		6G74	3.5L	99/09	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V75W	да	4WD	6G74	3.5L	99/09	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V65W	да	4WD	6G74	3.5L	99-02	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V65W	да	4WD	6G74	3.5L	99-02	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V65W	да	4WD	6G74	3.5L	02/08	JCT0074A	M445A50	MR580733	L	внешний
Mitsubishi	Pajero	V65W	да	4WD	6G74	3.5L	02/08	JCT0074A	M445A50	MR580734	R	внешний
Mitsubishi	Pajero	V75W	да	4WD	6G74	3.5L	99-02	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V75W	да	4WD	6G74	3.5L	99-02	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Pajero	V75W	да	4WD	6G74	3.5L	02/08	JCT0074A	M445A50	MR580733	L	внешний
Mitsubishi	Pajero	V75W	да	4WD	6G74	3.5L	02/08	JCT0074A	M445A50	MR580734	R	внешний
Mitsubishi	Pajero	V75W	да	4WD	6G74	3.5L	02/08	JCT0074A	M445A50	MR453384	R	внешний
Mitsubishi	Pajero	V75W	да	4WD	6G74	3.5L	02/08	JCT0074A	M445A50	MR453383	L	внешний
Mitsubishi	Space Star	V75W	да	4WD	6G74	3.5L	98-	JCT0099A	M445A50	MR377715	L	внешний
Mitsubishi	Space Star		да		4G13	1.3L	98-	JCT0099A		MR377715	L	внешний
Mitsubishi	Space Star		да		4G13	1.3L	98-	JCT0099A		MR910890	R	внешний
NISSAN												
Nissan	AD Van Wingroad AD	WFY11, WFY11	да		QG15DE	1.5L	99-06-	JCT0024A	NI-017A42	391004M776	R	внешний
Nissan	AD Van Wingroad AD	WFY11, WFY11	да		QG15DE	1.5L	99-06-	JCT0024A	NI-017A42	391004M771	R	внешний
Nissan	AD Van/Wagon Max AD	V/W FY10, FGY1	да		GA15DS	1.5L	95-06-99-06	JCT0024A	NI-017A42	3910060Y15	R	внешний
Nissan	AD Van/Wagon Max AD	VFN/ WFNY10	да	4WD	GA15DS E	1.5L	90-10-96-05	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	AD Van/Wagon Max AD	VFN/ WFNY10	да	4WD	GA15DS E	1.5L	90-10-96-08	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-05-93-01	JCT0166A	NI-019A42	3910071N15	R	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-05-93-01	JCT0166A	NI-019A42	3910070N10	R	внешний
Nissan	Avenir	VSW10	да		CD20	2.0L	90-05-93-01	JCT0166A	NI-019A42	3910071N15	R	внешний
Nissan	AD Van Wingroad AD	WFY11, WFY11	да		QG15DE	1.5L	99-06-	JCT0024A	NI-017A42	391014M771	L	внешний
Nissan	AD Van Wingroad AD	WFY11, WFY11	да		QG15DE	1.5L	99-06-	JCT0024A	NI-017A42	391014M771	L	внешний
Nissan	AD Van/Wagon Max AD	V/W FY10, FGY1	да		GA15DS	1.5L	95-06-99-06	JCT0024A	NI-017A42	3910160Y15	L	внешний
Nissan	AD Van/Wagon Max AD	VFN/ WFNY10	да	4WD	GA15DS E	1.5L	90-10-96-05	JCT0024A	NI-017A42	3910162Y16	L	внешний
Nissan	AD Van/Wagon Max AD	VFN/ WFNY10	да	4WD	GA15DS E	1.5L	90-10-96-08	JCT0024A	NI-017A42	3910162Y15	L	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-05-93-01	JCT0166A	NI-019A42	3910170N15	L	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-05-93-01	JCT0166A	NI-019A42	3910170N10	L	внешний
Nissan	Avenir	PKW10	да	4WD	SR20DE	2.0L	90-10-95-08	JCT0166A	NI-019A42	3910175N10	L	внешний
Nissan	Avenir	VSW10	да		CD20	2.0L	90-05-93-01	JCT0166A	NI-019A42	3910180N15	L	внешний
Nissan	Avenir	VSW10	да		CD20	2.0L	90-05-93-01	JCT0166A	NI-019A42	3910171N10	L	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-93	JCT0025A	NI19A42	3910071N15	R	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-93	JCT0025A	NI19A42	3910170N15	L	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-93	JCT0025A	NI19A42	3910070N10	R	внешний
Nissan	Avenir	VEW10	да		GA16DS	1.6L	90-93	JCT0025A	NI19A42	3910170N10	L	внешний
Nissan	Avenir	VSW10	да		CD20	2.0L	90-93	JCT0025A	NI19A42	3910071N15	R	внешний
Nissan	Avenir	VSW10	да		CD20	2.0L	90-93	JCT0025A	NI19A42	3910180N15	L	внешний

Nissan	Bluebird	ENU14	да	4WD	SR18DE	1.8L	96.01-	JCT0166A	NI-019A42	3910065J10	R	внешний
Nissan	Bluebird	ENU14	да	4WD	SR18DE	1.8L	96.01-	JCT0166A	NI-019A42	391003J210	R	внешний
Nissan	Bluebird	RNU12	да	4WD	CA18	1.8L	87.09-89.10	JCT0166A	NI-019A42	3,91E+16	R	внешний
Nissan	Bluebird	RU12	да		CA18	1.8L	87.09-89.10	JCT0166A	NI-019A42	3,91E+16	R	внешний
Nissan	Bluebird	HNU14	да	4WD	SR20DE	2.0L	96.01-	JCT0166A	NI-019A42	3910065J10	R	внешний
Nissan	Bluebird	HNU14	да	4WD	SR20DE	2.0L	96.01-	JCT0166A	NI-019A42	391003J210	R	внешний
Nissan	Bluebird	ENU14	да	4WD	SR18DE	1.8L	96.01-	JCT0166A	NI-019A42	3910165J15	L	внешний
Nissan	Bluebird	ENU14	да	4WD	SR18DE	1.8L	96.01-	JCT0166A	NI-019A42	391013J210	L	внешний
Nissan	Bluebird	RNU12	да	4WD	CA18	1.8L	87.09-89.10	JCT0166A	NI-019A42	3,91E+16	L	внешний
Nissan	Bluebird	RU12	да		CA18	1.8L	87.09-89.10	JCT0166A	NI-019A42	3,91E+16	L	внешний
Nissan	Bluebird	HNU14	да	4WD	SR20DE	2.0L	96.01-	JCT0166A	NI-019A42	3910165J15	L	внешний
Nissan	Bluebird	HNU14	да	4WD	SR20DE	2.0L	96.01-	JCT0166A	NI-019A42	391013J210	L	внешний
Nissan	Bluebird	HU14	да		SR20DE	2.0L	96.01-	JCT0166A	NI-019A42	391012J210	L	внешний
Nissan	Bluebird	EU14	да		SR18DE	1.8L	96.01	JCT0029A	NI34A44	391003J110	R	внешний
Nissan	Bluebird	EU14	да		SR18DE	1.8L	96.01	JCT0029A	NI34A44	391010E417	L	внешний
Nissan	Bluebird	U14	да		CD20	2.0L	96.01	JCT0029A	NI34A44	392115V471	R/L	внешний
Nissan	Bluebird	ENU14	да	4WD	SR18DE	1.8L	96.01	JCT0025A	NI19A42	3910065J10	R	внешний
Nissan	Bluebird	ENU14	да	4WD	SR18DE	1.8L	96.01	JCT0025A	NI19A42	3910165J15	L	внешний
Nissan	Bluebird	RNU12	да	4WD	CA18	1.8L	87.89	JCT0025A	NI19A42	3910064E10	R	внешний
Nissan	Bluebird	RNU12	да	4WD	CA18	1.8L	87.89	JCT0025A	NI19A42	3910164E10	L	внешний
Nissan	Bluebird	U13	да		CAI6DS	1.6L	91.95	JCT0028		391000E705	R	внешний
Nissan	Bluebird	U13	да		CAI6DS	1.6L	91.95	JCT0028		391010E705	L	внешний
Nissan	Bluebird	U13	да		CAI6DS	1.6L	91.95	JCT0028		391000E700	R	внешний
Nissan	Bluebird	U13	да		CAI6DS	1.6L	91.95	JCT0028		391010E700	L	внешний
Nissan	Bluebird	PU13	да		KA24DE	2.4L	93.08.95.11	JCT0030	NI-036	391002B015	R	внешний
Nissan	Bluebird Stylphy	G10	да		QC18DE	1.8L	00.08.	JCT0024A	NI-017A42	391004M776	R	внешний
Nissan	Bluebird Stylphy	QG10	да		QC18DE	1.8L	00.08.	JCT0024A	NI-017A42	391004M776	R	внешний
Nissan	Bluebird Stylphy	G10	да		QR20DD	2.0L	00.08.	JCT0024A	NI-017A42	391006N215	R	внешний
Nissan	Bluebird Stylphy	TG10	да		QR20DD	2.0L	00.08.	JCT0024A	NI-017A42	391006N215	R	внешний
Nissan	Bluebird	PU13	да		KA24DE	2.4L	93.08.95.11	JCT0030	NI-036	391012B016	L	внешний
Nissan	Bluebird Stylphy	G10	да		QC18DE	1.8L	00.08.	JCT0024A	NI-017A42	391014M771	L	внешний
Nissan	Bluebird Stylphy	QG10	да		QC18DE	1.8L	00.08.	JCT0024A	NI-017A42	391014M771	L	внешний
Nissan	Bluebird Stylphy	G10	да		QR20DD	2.0L	00.08.	JCT0024A	NI-017A42	391016N251	L	внешний
Nissan	Bluebird Stylphy	TG10	да		QR20DD	2.0L	00.08.	JCT0024A	NI-017A42	391016N215	L	внешний
Nissan	California	Y10	да		GA15D	1.5L	90.10-06.95	JCT0023A	NI13A42	3910051Y10	R	внешний
Nissan	California	Y10	да		GA15D	1.5L	90.10-06.95	JCT0023A	NI13A42	3910151Y10	L	внешний
Nissan	California	Y10	да		GA15D	1.5L	90.10-06.95	JCT0023A	NI13A42	3910050Y10	R	внешний
Nissan	California	Y10	да		GA15D	1.5L	90.10-06.95	JCT0023A	NI13A42	3910150Y10	L	внешний
Nissan	California	Y10	да		GA15D	1.5L	95.06-96.05	JCT0024A	NI-017A42	3910060Y15	R	внешний
Nissan	California	Y10	да	4WD	GA15	1.5L	90.10-96.05	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	California	Y10	да	4WD	GA15	1.5L	90.10-96.05	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Caravan Elgrand	E50	да	4WD	QD32ETI	3.2L	97.05-99.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Caravan Elgrand	E50	да	4WD	VG33E	3.3L	97.05-00.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	California	Y10	да		GA15D	1.5L	95.06-96.05	JCT0024A	NI-017A42	3910160Y15	L	внешний
Nissan	California	Y10	да	4WD	GA15	1.5L	90.10-96.05	JCT0024A	NI-017A42	3910162Y16	L	внешний
Nissan	California	Y10	да	4WD	GA15	1.5L	90.10-96.05	JCT0024A	NI-017A42	3910162Y15	L	внешний
Nissan	Caravan Elgrand	E50	да	4WD	QD32ETI	3.2L	97.05-99.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Caravan Elgrand	E50	да	4WD	VG33E	3.3L	97.05-00.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Cefiro	A33	да		VQ20DE	2.0L	01-02	JCT0076A	NI72A44	391002Y210	R	внешний
Nissan	Cefiro	A33	да		VQ20DE	2.0L	01-02	JCT0076A	NI72A44	391012Y215	L	внешний
Nissan	Cefiro	A33	да		VQ20DE	2.0L	98-02	JCT0076A	NI72A44	391002Y076	R	внешний
Nissan	Cefiro	A33	да		VQ20DE	2.0L	98-02	JCT0076A	NI72A44	391012Y076	L	внешний
Nissan	Cefiro	A33	да		VQ20DE	2.0L	98-02	JCT0076A	NI72A44	392112Y210	R/L	внешний
Nissan	Cefiro / Maxima	A32	да		VQ20DE	2.0L	94-98	JCT0027A	NI27A46	3910032U15	R	внешний
Nissan	Cefiro / Maxima	A32	да		VQ20DE	2.0L	94-98	JCT0027A	NI27A46	3910132U15	L	внешний
Nissan	Cefiro / Maxima	A32	да		VQ20DE	2.0L	94-98	JCT0027A	NI27A46	3910031U10	R	внешний
Nissan	Cefiro / Maxima	A32	да		VQ20DE	2.0L	94-98	JCT0027A	NI27A46	3910131U10	L	внешний
Nissan	Cefiro / Maxima	PA32	да		VQ25DE	2.5L	94-98	JCT0027A	NI27A46	3910032U15	R	внешний
Nissan	Cefiro / Maxima	PA32	да		VQ25DE	2.5L	94-98	JCT0027A	NI27A46	3910132U15	L	внешний
Nissan	Cefiro / Maxima	PA33	да		VQ25DD	2.5L	98-01	JCT0027A	NI27A46	391002Y115	R	внешний
Nissan	Cefiro / Maxima	PA33	да		VQ25DD	2.5L	98-01	JCT0027A	NI27A46	391012Y116	L	внешний
Nissan	Cefiro / Maxima	HA32	да		VQ30DE	2.5L	94-01	JCT0027A	NI27A46	3910032U15	R	внешний
Nissan	Cefiro / Maxima	HA32	да		VQ30DE	2.5L	94-01	JCT0027A	NI27A46	3910132U15	L	внешний
Nissan	Cefiro / Maxima	A33	да		VQ20DE	2.0	98-02	JCT0038A	NI69A44	391002Y175	R	внешний
Nissan	Cefiro / Maxima	A33	да		VQ20DE	2.0	98-02	JCT0038A	NI69A44	391012Y070	L	внешний
Nissan	Cefiro / Maxima	A33	да		VQ20DE	2.0	98-01	JCT0038A	NI69A44	391002Y175	R	внешний
Nissan	Cefiro / Maxima	A33	да		VQ20DE	2.0	98-01	JCT0038A	NI69A44	391012Y176	L	внешний
Nissan	Cefiro / Maxima	A33	да		VQ20DE	2.0	98-01	JCT0038A	NI69A44	391012Y175	L	внешний
Nissan	Cefiro / Maxima	PA33	да		VQ25DD	2.5L	92-02	JCT0038A	NI69A44	391002Y175	R	внешний
Nissan	Cefiro / Maxima	PA33	да		VQ25DD	2.5L	92-02	JCT0038A	NI69A44	391012Y176	L	внешний
Nissan	Datsun	D21	да	4WD	Z20	2.0L	85.01-89.01	JCT0026	NI-024	3910031G00	R	внешний
Nissan	Elgrand	E50	да	4WD	ZD30DDTI	3.0L	99.08-02.05	JCT0035	NI-064	3910058G60	R	внешний
Nissan	Elgrand	E50	да	4WD	VQ35DE	3.5L	00.08-02.05	JCT0035	NI-064	3910058G60	R	внешний
Nissan	Homy Elgrand	E50	да	4WD	QD32ETI	3.2L	97.05-99.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Homy Elgrand	E50	да	4WD	VG33E	3.3L	97.05-00.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Largo	ED7	да	4WD	KA24DE	2.4L	93.05.	JCT0166A	NI-019A42	—	R	внешний
Nissan	Largo	ED7	да	4WD	KA24DE	2.4L	93.05.	JCT0166A	NI-019A42	391005CS10	R	внешний
Nissan	Largo	ED7	да	4WD	KA24DE	2.4L	93.05.	JCT0166A	NI-019A42	392115CS10	R	внешний
Nissan	Largo	W30	да	4WD	KA24DE	2.4L	93.05-96.10	JCT0166A	NI-019A42	—	R	внешний
Nissan	Largo	W30	да	4WD	KA24DE	2.4L	93.05-96.10	JCT0166A	NI-019A42	391005CS10	R	внешний
Nissan	Largo	W30	да	4WD	KA24DE	2.4L	96.10-99.06	JCT0166A	NI-019A42	391001C110	R	внешний

Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0166A	NI-019A42	---	R	внешний
Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0166A	NI-019A42	391005C510	R	внешний
Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0166A	NI-019A42	392115C510	R	внешний
Nissan	Largo	W30	да	4WD	CD20TI	2.0L	93.05-96.10	JCT0166A	NI-019A42	---	R	внешний
Nissan	Largo	W30	да	4WD	CD20TI	2.0L	93.05-96.10	JCT0166A	NI-019A42	391005C510	R	внешний
Nissan	Largo	W30	да	4WD	CD20TI	2.0L	96.10-99.06	JCT0166A	NI-019A42	391001C110	R	внешний
Nissan	Datsun	D21	да	4WD	Z20	2.0L	85.01-89.01	JCT0026	NI-024	3910031G00	L	внешний
Nissan	Elgrand	E50	да	4WD	ZD30DDTI	3.0L	99.08-02.05	JCT0035	NI-064	3910058G60	L	внешний
Nissan	Elgrand	E50	да	4WD	VQ35DE	3.5L	00.08-02.05	JCT0035	NI-064	3910058G60	L	внешний
Nissan	Homy Elgrand	E50	да	4WD	QD32ETI	3.2L	97.05-99.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Homy Elgrand	E50	да	4WD	VG33E	3.3L	97.05-00.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Largo	ED7	да	4WD	KA24DE	2.4L	93.05-	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Largo	ED7	да	4WD	KA24DE	2.4L	93.05-	JCT0166A	NI-019A42	391005C510	L	внешний
Nissan	Largo	ED7	да	4WD	KA24DE	2.4L	93.05-	JCT0166A	NI-019A42	392115C510	L	внешний
Nissan	Largo	W30	да	4WD	KA24DE	2.4L	93.05-96.10	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Largo	W30	да	4WD	KA24DE	2.4L	93.05-96.10	JCT0166A	NI-019A42	391005C510	L	внешний
Nissan	Largo	W30	да	4WD	KA24DE	2.4L	96.10-99.06	JCT0166A	NI-019A42	391001C110	L	внешний
Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0166A	NI-019A42	391005C510	L	внешний
Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0166A	NI-019A42	392115C510	L	внешний
Nissan	Largo	W30	да	4WD	CD20TI	2.0L	93.05-96.10	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Largo	W30	да	4WD	CD20TI	2.0L	93.05-96.10	JCT0166A	NI-019A42	391005C510	L	внешний
Nissan	Largo	W30	да	4WD	CD20TI	2.0L	96.10-99.06	JCT0166A	NI-019A42	391001C110	L	внешний
Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0025A	NI19A42	391005C510	R/L	внешний
Nissan	Largo	UD7	да	4WD	CD20TI	2.0L	93.05-	JCT0025A	NI19A42	392115C510	R/L	внешний
Nissan	Largo	W30	да	4WD	CD20TI	2.0L	93.96	JCT0025A	NI19A42	391005C510	R/L	внешний
Nissan	Largo	ED7	да	4WD	KA24DE	2.4L	93.05-	JCT0025A	NI19A42	391005C510	R/L	внешний
Nissan	Largo	W30	да	4WD	KA24DE	2.4L	93.96	JCT0025A	NI19A42	391005C510	R/L	внешний
Nissan	March / Micra	K11	да	4WD	CG10DE	1.0L	92.95	JCT0031A	N43A42	3910045B00	R	внешний
Nissan	March / Micra	K11	да	4WD	CG10DE	1.0L	92.95	JCT0031A	N43A42	3910145B00	L	внешний
Nissan	March / Micra	K11	да	4WD	CG10DE	1.0L	92.01-	JCT0031A	N43A42	391004F100	R	внешний
Nissan	March / Micra	K11	да	4WD	CG10DE	1.0L	92.01-	JCT0031A	N43A42	391014F100	L	внешний
Nissan	March / Micra	K11	да	4WD	CG10DE	1.0L	92.97	JCT0031A	N43A42	3910041B10	R	внешний
Nissan	March / Micra	K11	да	4WD	CG10DE	1.0L	92.97	JCT0031A	N43A42	3910141B10	L	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.01	JCT0031A	N43A42	3910044B12	R	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.01	JCT0031A	N43A42	3910044B10	R	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.01	JCT0031A	N43A42	3910144B12	L	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.01	JCT0031A	N43A42	3910144B10	L	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.95	JCT0031A	N43A42	3910044B10	R	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.95	JCT0031A	N43A42	3910144B10	L	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.97	JCT0031A	N43A42	3910044B12	R	внешний
Nissan	March / Micra	HK11	да	4WD	CG13DE	1.3L	92.97	JCT0031A	N43A42	3910144B12	L	внешний
Nissan	March / Micra	K12	да	4WD	CR10DE	1.0L	02.02	JCT0075	Ni68	39100AX005	R	внешний
Nissan	March / Micra	K12	да	4WD	CR10DE	1.0L	02.02	JCT0075	Ni68	39101AX005	L	внешний
Nissan	March / Micra	K12	да	4WD	CR12DE	1.2L	02.02	JCT0075	Ni68	39101AX005	L	внешний
Nissan	March / Micra	K12	да	4WD	CR12DE	1.2L	02.02	JCT0075	Ni68	39100AX000	R	внешний
Nissan	March / Micra	K12	да	4WD	CR12DE	1.2L	02.02	JCT0075	Ni68	39101AX000	L	внешний
Nissan	March / Micra	K12	да	4WD	CR14DE	1.4L	02.02	JCT0075	Ni68	39100AX005	R	внешний
Nissan	March / Micra	K12	да	4WD	CR14DE	1.4L	02.02	JCT0075	Ni68	39101AX005	L	внешний
Nissan	March / Micra	K12	да	4WD	CR14DE	1.4L	02.02	JCT0075	Ni68	39101AX005	L	внешний
Nissan	Micra III	K12	да	4WD	CR10DE	1.0L	03-	JCT0141		39211AY125	R/L	внешний
Nissan	Micra III	K12	да	4WD	CR12	1.2L	03-	JCT0141		39211AY125	R/L	внешний
Nissan	NX Coupe	EB13	да	4WD	GA16DE	1.6L	90.01-93.12	JCT0024A	NI-017A42	3910060Y15	R	внешний
Nissan	NX Coupe	EB13	да	4WD	GA16DE	1.6L	90.01-93.12	JCT0024A	NI-017A42	3910060Y10	R	внешний
Nissan	Prairie	NM11	да	4WD	CA20S	2.0L	88.09-95.08	JCT0166A	NI-019A42	3.91E+16	R	внешний
Nissan	Prairie	PNM11	да	4WD	SR20DW	2.0L	95.08-98.11	JCT0166A	NI-019A42	---	R	внешний
Nissan	Prairie	HNM11	да	4WD	KA24E	2.4L	90.09-95.08	JCT0166A	NI-019A42	3.91E+16	R	внешний
Nissan	Presea	R11	да	4WD	GA15DE	1.5L	95.01-97.08	JCT0024A	NI-017A42	391000M311	R	внешний
Nissan	Presea	PR10	да	4WD	SR18DI	1.8L	90.06-95.01	JCT0024A	NI-017A42	3910061Y16	R	внешний
Nissan	Presea	PR11	да	4WD	SR18DE	1.8L	95.01-97.08	JCT0024A	NI-017A42	3910040Y10	R	внешний
Nissan	NX Coupe	EB13	да	4WD	GA16DE	1.6L	90.01-93.12	JCT0024A	NI-017A42	3910160Y15	L	внешний
Nissan	NX Coupe	EB13	да	4WD	GA16DE	1.6L	90.01-93.12	JCT0024A	NI-017A42	3910160Y10	L	внешний
Nissan	Prairie	NM11	да	4WD	CA20S	2.0L	88.09-95.08	JCT0166A	NI-019A42	3.91E+16	L	внешний
Nissan	Prairie	PNM11	да	4WD	SR20DW	2.0L	95.08-98.11	JCT0166A	NI-019A42	3910175N10	L	внешний
Nissan	Prairie	HNM11	да	4WD	KA24E	2.4L	90.09-95.08	JCT0166A	NI-019A42	3.91E+16	L	внешний
Nissan	Presea	R11	да	4WD	GA15DE	1.5L	95.01-97.08	JCT0024A	NI-017A42	391010M311	L	внешний
Nissan	Presea	PR10	да	4WD	SR18DI	1.8L	90.06-95.01	JCT0024A	NI-017A42	3910161Y17	L	внешний
Nissan	Presea	PR11	да	4WD	SR18DE	1.8L	95.01-97.08	JCT0024A	NI-017A42	3910140Y10	L	внешний
Nissan	Primera	P11	да	4WD	DC1	1.9L	03.04	JCT0130A	NI070A44	39211AW325	R/L	внешний
Nissan	Primera / Camino	P11	да	4WD	SR18DE	1.8L	95.98	JCT0029A	N34A44	3910031171	R	внешний
Nissan	Primera / Camino	P11	да	4WD	SR18DE	1.8L	95.98	JCT0029A	N34A44	3910031110	R	внешний
Nissan	Primera / Camino	P11	да	4WD	SR20VE	2.0L	99.01	JCT0029A	N34A44	3910031171	R	внешний
Nissan	Primera / Camino	P11	да	4WD	SR20VE	2.0L	99.01	JCT0029A	N34A44	391010E478	L	внешний
Nissan	Primera / Camino	P12EDA	да	4WD	QG18DE	1.8L	02.02	JCT0039A	NI76A44	39100AU115	R	внешний
Nissan	Primera / Camino	P12EDA	да	4WD	QG18DE	1.8L	02.02	JCT0039A	NI76A44	39101AU075	L	внешний
Nissan	Primera / Camino	P11	да	4WD	SR20DE	2.0L	95.01	JCT0036A	NI65A44	391002J210	R	внешний
Nissan	Primera / Camino	P11	да	4WD	SR20DE	2.0L	95.01	JCT0036A	NI65A44	391012J210	L	внешний
Nissan	Primera / Camino	P11	да	4WD	SR20DE	2.0L	95.96	JCT0036A	NI65A44	391002J215	R	внешний
Nissan	Primera / Camino	P11	да	4WD	SR20DE	2.0L	95.96	JCT0036A	NI65A44	391012J215	L	внешний
Nissan	Primera / Camino	P11	да	4WD	SR18DE	1.8L	95.01	JCT0037A	NI66A44	391002J211	R	внешний

Nissan	Pulsar Lucino Almera	EN15	да		GA16DE	1.6L	95.01-	JCT0024A	NI-017A42	391010M311	L	внешний
Nissan	Rasheen	RFNB14	да		GA15DE	1.5L	94.12-97.01	JCT0024A	NI-017A42	3910162Y15	L	внешний
Nissan	Rasheen	RFNB14	да		GA15DE	1.5L	94.12-97.01	JCT0024A	NI-017A42	3910162Y15	L	внешний
Nissan	Serena	C23	да	4WD	SR20DE	2.0L	91.06-94.05	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Serena	C23	да	4WD	SR20DE	2.0L	91.06-94.05	JCT0166A	NI-019A42	391001C110	L	внешний
Nissan	Serena	C23	да	4WD	SR20DE	2.0L	91.06-94.05	JCT0166A	NI-019A42	392111C100	L	внешний
Nissan	Serena	C23	да	4WD	SR20DE	2.0L	94.05-97.01	JCT0166A	NI-019A42	391005C510	L	внешний
Nissan	Serena	C23	да	4WD	SR20DE	2.0L	94.05-97.01	JCT0166A	NI-019A42	392115C510	L	внешний
Nissan	Serena	C23	да	4WD	SR20DE	2.0L	97.01-99.06	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Serena	C23	да	4WD	CD20T	2.0L	91.06-94.05	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Serena	C23	да	4WD	CD20T	2.0L	91.06-94.05	JCT0166A	NI-019A42	391001C110	L	внешний
Nissan	Serena	C23	да	4WD	CD20T	2.0L	91.06-94.05	JCT0166A	NI-019A42	392111C100	L	внешний
Nissan	Serena	C23	да	4WD	CD20T	2.0L	94.05-97.01	JCT0166A	NI-019A42	391005C510	L	внешний
Nissan	Serena	C23	да	4WD	CD20T	2.0L	97.01-99.06	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Serena	C23	да	4WD	CD20ET	2.0L	97.01-99.06	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Serena	C23	да	4WD	CD20ET	2.0L	97.01-99.06	JCT0166A	NI-019A42	391001C100	L	внешний
Nissan	Sunny	B15	да		QG13DE	1.3L	98/10	JCT0033A	NI60A42	391004M475	R	внешний
Nissan	Sunny	B15	да		QG13DE	1.3L	98/10	JCT0033A	NI60A42	391014M475	L	внешний
Nissan	Sunny	B15	да		QG13DE	1.3L	98/10	JCT0033A	NI60A42	391004M470	R	внешний
Nissan	Sunny	B15	да		QG13DE	1.3L	98/10	JCT0033A	NI60A42	391014M470	L	внешний
Nissan	Sunny	B15	да		QG15DE	1.5L	98/10	JCT0033A	NI60A42	391004M475	R	внешний
Nissan	Sunny	B15	да		QG15DE	1.5L	98/10	JCT0033A	NI60A42	391014M475	L	внешний
Nissan	Sunny	B15	да		QG15DE	1.5L	98/10	JCT0033A	NI60A42	391004M470	R	внешний
Nissan	Sunny	B15	да		QG15DE	1.5L	98/10	JCT0033A	NI60A42	391014M470	L	внешний
Nissan	Sunny	B15	да		QG15DEL.EV	1.5L	98/10	JCT0033A	NI60A42	391004M475	R	внешний
Nissan	Sunny	B15	да		QG15DEL.EV	1.5L	98/10	JCT0033A	NI60A42	391014M475	L	внешний
Nissan	Sunny	B15	да		QG15DEL.EV	1.5L	98/10	JCT0033A	NI60A42	391004M470	R	внешний
Nissan	Sunny	B15	да		QG15DEL.EV	1.5L	98/10	JCT0033A	NI60A42	391014M470	L	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3910051Y10	R	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3910151Y10	L	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3010151Y10	L	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3910052Y00	R	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3910152Y00	L	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3910052Y10	R	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3010152Y10	L	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3910053Y10	R	внешний
Nissan	Sunny/ Sentra	B13	да		GA15DS	1.5L	90-94	JCT0023A	NI13A42	3010153Y10	L	внешний
Nissan	Sunny/ Sentra	B14	да		GA15DE	1.5L	94-98	JCT0023A	NI13A42	391000M015	R	внешний
Nissan	Sunny/ Sentra	B14	да		GA15DE	1.5L	94-98	JCT0023A	NI13A42	391010M015	L	внешний
Nissan	Sunny/ Sentra	B14	да		GA15DE	1.5L	94-98	JCT0023A	NI13A42	391000M010	R	внешний
Nissan	Sunny/ Sentra	B14	да		GA15DE	1.5L	94-98	JCT0023A	NI13A42	391010M010	L	внешний
Nissan	Sunny/ Sentra	B15	да		SR16VE	1.6L	98-00	JCT0034A	NI62A42	391006M010	R	внешний
Nissan	Sunny/ Sentra	B15	да		SR16VE	1.6L	98-00	JCT0034A	NI62A42	391016M010	L	внешний
Nissan	Sunny/ Sentra	B15	да		QG18DD	1.8L	98-00	JCT0034A	NI62A42	391005M810	R	внешний
Nissan	Sunny/ Sentra	B15	да		QG18DD	1.8L	98-00	JCT0034A	NI62A42	391015M810	L	внешний
Nissan	Sunny/ Sentra	B15	да		YD22DD	2.2L	99-02	JCT0034A	NI62A42	39100WD215	R	внешний
Nissan	Sunny/ Sentra	B15	да		YD22DD	2.2L	99-02	JCT0034A	NI62A42	39100WD210	R	внешний
Nissan	Sunny/ Sentra	B15	да		YD22DD	2.2L	99-02	JCT0034A	NI62A42	39101WD210	L	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	GA15DS	1.5L	90.01-94.01	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	GA15DS	1.5L	90.01-94.01	JCT0024A	NI-017A42	3910063Y10	R	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	GA15DS	1.5L	90.01-94.01	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	GA15DS	1.5L	90.01-94.01	JCT0024A	NI-017A42	3910063Y10	R	внешний
Nissan	Sunny/ Sentra	B14	да	4WD	GA15DE	1.5L	94.01-98.10	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Sunny/ Sentra	B14	да	4WD	GA15DE	1.5L	94.01-98.10	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Sunny/ Sentra	EB13	да		GA16DE	1.6L	90.01-94.01	JCT0024A	NI-017A42	3910060Y10	R	внешний
Nissan	Sunny/ Sentra	EB13	да		GA16DE	1.6L	90.01-94.01	JCT0024A	NI-017A42	3910060Y15	R	внешний
Nissan	Sunny/ Sentra	EB14	да		GA16DE	1.6L	94.01-98.10	JCT0024A	NI-017A42	391000M311	R	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	SR18DE	1.8L	90.01-94.01	JCT0024A	NI-017A42	3910063Y10	R	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	SR18DE	1.8L	90.01-94.01	JCT0024A	NI-017A42	3910063Y10	R	внешний
Nissan	Sunny/ Sentra	SB14	да		CD20	2.0L	94.01-98.10	JCT0024A	NI-017A42	391000M915	R	внешний
Nissan	Sunny/ Sentra	SB14	да		CD20	2.0L	94.01-98.10	JCT0024A	NI-017A42	391000M910	R	внешний
Nissan	Sunny/ Sentra	SNB14	да	4WD	CD20	2.0L	94.01-98.10	JCT0024A	NI-017A42	3910063Y10	R	внешний
Nissan	Terrano Pathfinder	D21	да	4WD	VG30E	3.0L	87.10-89.10	JCT0026	NI-024	3910031G00	R	внешний
Nissan	Terrano Pathfinder	BYD21	да	4WD	TD27T	2.7L	86.08-89.10	JCT0026	NI-024	3910031G00	R	внешний
Nissan	Terrano Pathfinder	D21	да	4WD	TG27E	2.7L	86.01-89.01	JCT0026	NI-024	3910031G00	R	внешний
Nissan	Terrano Pathfinder	D21	да	4WD	VG30E	3.0L	89.10-	JCT0035	NI-064	3910088G00	R	внешний
Nissan	Terrano Pathfinder	R50	да		VG33E	3.3L	95.09-02.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Terrano Pathfinder	R50	да	4WD	VG33E	3.3L	95.09-02.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Terrano Pathfinder	R50	да		TD27ETI	2.7L	95.09-99.02	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Terrano Pathfinder	R50	да	4WD	TD27ETI	2.7L	95.09-99.02	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Terrano Regulus	R50	да		VG33E	3.3L	96.08-02.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Terrano Regulus	R50	да		QD32ETI	3.0L	96.08-99.02	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Terrano Regulus	R50	да	4WD	ZD30DD	3.0L	99.02-02.08	JCT0035	NI-064	3910058G00	R	внешний
Nissan	Wingroad	WFNY10	да	4WD	GA15DE	1.5L	96.05-99.06	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Wingroad	WFNY10	да	4WD	GA15DE	1.5L	96.05-99.06	JCT0024A	NI-017A42	3910062Y15	R	внешний
Nissan	Wingroad	WFY10	да		GA15DE	1.5L	96.05-99.06	JCT0024A	NI-017A42	3910060Y15	R	внешний
Nissan	Wingroad	WHNY10	да		SR18DE	1.8L	96.05-96.09	JCT0024A	NI-017A42	3910063Y10	R	внешний
Nissan	Wingroad	WHNY10	да		SR18DE	1.8L	96.05-96.09	JCT0024A	NI-017A42	3910063Y10	R	внешний
Nissan	Wingroad	WHY11	да		QG18DE	1.8L	99.06-	JCT0024A	NI-017A42	391004M776	R	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	GA15DS	1.5L	90.01-94.01	JCT0024A	NI-017A42	3910162Y15	L	внешний
Nissan	Sunny/ Sentra	B13	да	4WD	GA15DS	1.5L	90.01-94.01	JCT0024A	NI-017A42	3910163Y10	L	внешний

Nissan	Sunny/Sentra	B13	да	4WD	GA15DS		1.5L	90.01-94.01	JCT0024A	NI-017A42	3910162Y16	L	внешний
Nissan	Sunny/Sentra	B13	да	4WD	GA15DS		1.5L	90.01-94.01	JCT0024A	NI-017A42	3910163Y15	L	внешний
Nissan	Sunny/Sentra	B14	да	4WD	GA15DE		1.5L	94.01-98.10	JCT0024A	NI-017A42	3910162Y16	L	внешний
Nissan	Sunny/Sentra	B14	да	4WD	GA15DE		1.5L	94.01-98.10	JCT0024A	NI-017A42	3910162Y15	L	внешний
Nissan	Sunny/Sentra	EB13	да		GA16DE		1.6L	90.01-94.01	JCT0024A	NI-017A42	3910160Y10	L	внешний
Nissan	Sunny/Sentra	EB13	да		GA16DE		1.6L	90.01-94.01	JCT0024A	NI-017A42	3910160Y15	L	внешний
Nissan	Sunny/Sentra	EB14	да		GA16DE		1.6L	94.01-98.10	JCT0024A	NI-017A42	391010M311	L	внешний
Nissan	Sunny/Sentra	B13	да	4WD	SR18DE		1.8L	90.01-94.01	JCT0024A	NI-017A42	3910163Y15	L	внешний
Nissan	Sunny/Sentra	B13	да	4WD	SR18DE		1.8L	90.01-94.01	JCT0024A	NI-017A42	3910163Y10	L	внешний
Nissan	Sunny/Sentra	SB14	да		CD20		2.0L	94.01-98.10	JCT0024A	NI-017A42	391010M915	L	внешний
Nissan	Sunny/Sentra	SB14	да		CD20		2.0L	94.01-98.10	JCT0024A	NI-017A42	391010M910	L	внешний
Nissan	Sunny/Sentra	SNB14	да	4WD	VG20		2.0L	94.01-98.10	JCT0024A	NI-017A42	3910163Y10	L	внешний
Nissan	Terrano Parthfinder	D21	да	4WD	VG30E		3.0L	87.10-89.10	JCT0026	NI-024	3910031G00	L	внешний
Nissan	Terrano Parthfinder	BYD21	да	4WD	TD27T		2.7L	86.08-89.10	JCT0026	NI-024	3910031G00	L	внешний
Nissan	Terrano Parthfinder	D21	да	4WD	TG27E		2.7L	86.01-89.01	JCT0026	NI-024	3910031G00	L	внешний
Nissan	Terrano Parthfinder	D21	да	4WD	VG30E		3.0L	89.10	JCT0035	NI-064	3910088G00	L	внешний
Nissan	Terrano Parthfinder	R50	да		VG33E		3.3L	95.09-02.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Terrano Parthfinder	R50	да	4WD	VG33E		3.3L	95.09-02.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Terrano Parthfinder	R50	да		TD27ETI		2.7L	95.09-99.02	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Terrano Parthfinder	R50	да	4WD	TD27ETI		2.7L	95.09-99.02	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Terrano Regulus	R50	да		VG33E		3.3L	96.08-02.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Terrano Regulus	R50	да		QD32ETI		3.0L	96.08-99.02	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Terrano Regulus	R50	да	4WD	ZD30DD		3.0L	99.02-02.08	JCT0035	NI-064	3910058G00	L	внешний
Nissan	Wingroad	WFNY10	да	4WD	GA15DE		1.5L	96.05-99.06	JCT0024A	NI-017A42	3910162Y15	L	внешний
Nissan	Wingroad	WFNY10	да	4WD	GA15DE		1.5L	96.05-99.06	JCT0024A	NI-017A42	3910162Y16	L	внешний
Nissan	Wingroad	WFY10	да		GA15DE		1.5L	96.05-99.06	JCT0024A	NI-017A42	3910160Y15	L	внешний
Nissan	Wingroad	WHNY10	да		SR18DE		1.8L	96.05-96.09	JCT0024A	NI-017A42	3910163Y15	L	внешний
Nissan	Wingroad	WHNY10	да		SR18DE		1.8L	96.05-96.09	JCT0024A	NI-017A42	3910163Y05	L	внешний
Nissan	Wingroad	WHY11	да		QG18DE		1.8L	99.06	JCT0024A	NI-017A42	391014M771	L	внешний
Nissan	X-TRAIL	NT30	да	4WD	QR20DE		2.0L	00/10	JCT0038A	NI69A44	391008H515	R	внешний
Nissan	X-TRAIL	NT30	да		QR20DE		2.0L	00/10	JCT0038A	NI69A44	392112Y070	R/L	внешний
Nissan	X-TRAIL	NT30	да		QR20DE		2.0L	00/10	JCT0038A	NI69A44	391008H315	R	внешний
Nissan	X-TRAIL	NT30	да		QR20VET		2.0L	00/10	JCT0038A	NI69A44	391008H615	R	внешний
Nissan	X-TRAIL	NT30	да		QR20VET		2.0L	00/10	JCT0038A	NI69A44	392112Y070	R/L	внешний
Nissan	X-TRAIL	NT30	да		QR20DE		2.0L	00/10	JCT0038A	NI69A44	391018H315	L	внешний
Nissan	X-TRAIL	NT30	да		QR20DE		2.0L	00/10	JCT0038A	NI69A44	391018H810	L	внешний
Nissan	X-TRAIL	NT30	да		QR20VET		2.0L	00/10	JCT0038A	NI69A44	391018H315	L	внешний
OPEL													
Opel	Meriva A 1.6		да		Z16SE	Petrol	1.6L	5/03-	JCT0151A		1603251	R/L	внешний
Opel	Meriva A 1.6 16v		да		Z16XE	Petrol	1.6L	5/03-	JCT0151A		1603251	R/L	внешний
Opel	Astra Classic F		да		X14NZ/ C/ SZ		1.4L i	98-04	JCT0114A		374263	R/L	внешний
Opel	Astra F		да		C14NZ		1.4i	94-98	JCT0114A		374263	R/L	внешний
Opel	Astra F VAN	55			X16SZ		1.6L i	93-	JCT0148		374003	R/L	внешний
Opel	Astra H (Cabriolet)				Z18XER		1.8L	08-09	JCT0153		0374672	R/L	внешний
Opel	Astra H (Cabriolet)				Z18XER		1.8L	05-	JCT0153		1603274	R/L	внешний
Opel	Astra H (Cabriolet)				Z16LET		1.6L	06-	JCT0153		0374672	R/L	внешний
Opel	Astra H (Cabriolet)				Z18XE		1.6L	05-	JCT0153		1603274	R/L	внешний
Opel	Astra H (Cabriolet)				Z12XEP		1.2L	05-	JCT0124		1603273	R/L	внешний
Opel	Astra H (Cabriolet)				Z16XEP		1.6L	05-	JCT0124		374671	R/L	внешний
Opel	Astra H (Cabriolet)				Z16XER		1.6L	06-	JCT0124		1603273	R/L	внешний
Opel	Astra H Cabrio				Z20LEL		2.0L	05-	JCT0152		1603270	R/L	внешний
Opel	Astra H Cabrio				Z20LER		2.0L	05-	JCT0152		93182571	R/L	внешний
Opel	Astra H GTC				Z20LER		2.0L	04-	JCT0152			R/L	внешний
Opel	Astra H GTC				Z18XER		1.8L	08-	JCT0153		0374672	R/L	внешний
Opel	Astra H GTC				Z16LET		1.6L	07-	JCT0153		1603274	R/L	внешний
Opel	Astra H GTC				Z18XE		1.8L	04-	JCT0153		0374672	R/L	внешний
Opel	Astra H GTC				Z17DTL	Diesel	1.7L	04-	JCT0153		1603274	R/L	внешний
Opel	Astra H GTC				Z13DTH	Diesel	1.3L CDti	05-	JCT0153		0374672	R/L	внешний
Opel	Astra H GTC				Z17DTH	Diesel	1.7L CDti	04-09	JCT0153		1603274	R/L	внешний
Opel	Astra H GTC				Z18XER		1.8L	08-	JCT0124		374671	R/L	внешний
Opel	Astra H GTC				Z18XER		1.8L	07-	JCT0124		1603273	R/L	внешний
Opel	Astra H GTC				X12XE		1.2L	06-09	JCT0124		374671	R/L	внешний
Opel	Astra H GTC				Z14XEL		1.4L	04-	JCT0124		1603273	R/L	внешний
Opel	Astra H GTC				Z12XEP		1.2L	05-	JCT0124		374671	R/L	внешний
Opel	Astra H GTC				Z14XEP		1.4L	04-	JCT0124		1603273	R/L	внешний
Opel	Astra H GTC				Z16XEP		1.6L	04-	JCT0124		374671	R/L	внешний
Opel	Astra H GTC				Z16XER		1.6L	07-	JCT0124		1603273	R/L	внешний
Opel	Astra H GTC				Z19DTL	Diesel	1.9L CD Ti	07-	JCT0124		374671	R/L	внешний
Opel	Corsa		да		Z10XE		1.0L	00-	JCT0149A		374368	R/L	внешний
Opel	Corsa C/ Corsa II		да		Z18XE		1.8L	00-	JCT0150A		0374403	R/L	внешний
Opel	Meriva A		да		Z18XE		1.8L	03-	JCT0150A		0374403	R/L	внешний
Opel	Meriva A		да		Z13DTJ	Diesel	1.3L	03-	JCT0150A		0374403	R/L	внешний
Opel	Meriva A		да		Y17DT	Diesel	1.7L	03-	JCT0150A		0374403	R/L	внешний
Opel	Meriva A				Z16SE		1.6L	03-	JCT0148		90538595	R/L	внешний
Opel	Meriva A		да		Z16XE		1.6L	03-	JCT0149		1603251	R/L	внешний
Opel	Omega				Z3DTR/ YDT	Diesel	2.3 TDi	86-94	JCN0109		6383341734	R/L	внешний
Opel	Tigra				X14XE		1.4L i	94-00	JCN0154		374091	R/L	внешний
Opel	Tigra				X14XE		1.4L i	94-00	JCN0154		7839614	R/L	внешний
Opel	Zafira				Z16XNT		1.6L	09-	JCT0124		1603273	R/L	внешний
Opel	Zafira				Z16XEP		1.6L	05/10	JCT0124		374671	R/L	внешний
Opel	Zafira				Z16XER		1.6L	08-	JCT0124		1603273	R/L	внешний

Opel	Zafira			Z16YNG		1.6L	08-	JCT0124		374671		R/L	внешний
PEUGEOT													
Peugeot	206 (CABRIO)	2A/C	да	NFU(TU5JP4)		1.6L	00-	JCT0103A		3272AE		R/L	внешний
Peugeot	206 (CABRIO)	2A/C	да	NFU(TU5JP4)		1.6L	00-	JCT0103A		3273AL		R/L	внешний
Peugeot	307 I	3A/C/E		NFU(TU5JP4)		1.6L	00-	JCT0144		32725X		R/L	внешний
Peugeot	307 I	3A/C/E		KFW(TU3JP)		1.4L	00-	JCT0144		3272KY		R/L	внешний
Peugeot	307 I	3A/C/E		KFW(TU3JP)		1.4L	00-	JCT0144		3272LA		R/L	внешний
Peugeot	307 I	3A/C/E		KFW(TU3JP)		1.4L	00-	JCT0144		3273AH		R/L	внешний
Peugeot	307 I	3A/C/E		KFW(TU3JP)		1.4L	00-	JCT0144		3273KL		R/L	внешний
Peugeot	307 I	3A/C/E		KFW(TU3JP)		1.4L	00-	JCT0144		3273KP		R/L	внешний
RENAULT													
Renault	Chio II	C/B0/LB/CB0F/A, B/CB10/K, B/CB2 D	да	D7F710/ 720/ 726		1.2L	98-02	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	B/C/B0/LB/CB0C	да	E7J780		1.4L	98-09	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	B/C/B0/LB/CB0D	да	K7M744/ 745		1.6L	98-01	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	B/C/B0/LB/CB0L	да	K4J712/ 713		1.4L	99-00	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	B/C/B0/LB/CB0H	да	K4M708/ 748		1.6L	98-01	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	B/C/B0/LB/CB0P	да	K4J700/ 712/ 713		1.4L	00-	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	B/C/B0/LB/CB0E	да	F8Q606/ 630/ 632/ 662	Diesel	1.9L	98-	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	B/C/B0/LB/CB0U	да	F9Q780	Diesel	1.9L	00-	JCT0115A		7700110484		R/L	внешний
Renault	Chio II	BR0/L, CR0/1	да	K4M804		1.6L	05-	JCT0155A		6001548720		R/L	внешний
Renault	Chio II	BR0/L, CR0/1	да	K4M800/ 801		1.6L	05-	JCT0155A		8200264664		R/L	внешний
Renault	Chio Van II	SB0, SB0E	да	F8Q606/ 630/ 662	Diesel	1.9L	98-	JCT0115A		7700110484		R/L	внешний
Renault	Chio Van II	SB0	да	K9K700/ 704	Diesel	1.5L	01-	JCT0115A		7700110484		R/L	внешний
Renault	Dacia Logan I	MCV	да	K4M690/ 694		1.6L	06-	JCT0155A		391000153R		R/L	внешний
Renault	Dacia Logan I	MCV	да	K9K790	Diesel	1.5L	05-	JCT0155A		391015451R		R/L	внешний
Renault	Dacia Logan I	MCV	да	K9K792	Diesel	1.5L	06-	JCT0155A		6001548720		R/L	внешний
Renault	Kangoo I	KC0.KC0A/K/F/1	да	D7F710/ 720/ 722/ 726/ 746		1.2L	98-	JCT0115A		7700110484		R/L	внешний
Renault	Kangoo I	KC0.KC0C/H/B/M	да	K7J700/ 701		1.4L	98-	JCT0115A		7700110484		R/L	внешний
Renault	Kangoo I	KC0	да	E7J634/ 635/ 780		1.4L	98-	JCT0115A		7700110484		R/L	внешний
Renault	Kangoo I	KC0, KC0D	да	F8Q662	Diesel	1.9L	98-	JCT0115A		7700110484		R/L	внешний
Renault	Kangoo I	KC0.KC03/5/6/T/W	да	D4F712/ 714/ 716		1.2L	01-	JCT0107A		7700111918		R/L	внешний
Renault	Kangoo I	KC0.KC07	да	K9K700/ 704	Diesel	1.5L DCI	01-	JCT0107A		8200064731		R/L	внешний
Renault	Laguna II	B74.BGGG	да	F9Q670/ 750/ 756	Diesel	1.9L DCI		JCT0156		7711134777		R/L	внешний
Renault	Laguna II	B74.BGGG	да	F9Q670/ 750/ 756	Diesel	1.9L DCI		JCT0156		7711134778		R/L	внешний
Renault	Laguna II	B74.BGGG	да	F9Q670/ 750/ 756	Diesel	1.9L DCI		JCT0156		8200079912		R/L	внешний
Renault	Laguna II	B74.BGGG	да	F9Q670/ 750/ 756	Diesel	1.9L DCI		JCT0156		8200079913		R/L	внешний
Renault	Laguna II	B74.BGGG	да	F9Q670/ 750/ 756	Diesel	1.9L DCI		JCT0156		8200079914		R/L	внешний
Renault	Laguna II	B74.BGGG	да	F9Q670/ 750/ 756	Diesel	1.9L DCI		JCT0156		8200169176		R/L	внешний
Renault	Laguna II	B74.BGGG	да	F9Q670/ 750/ 756	Diesel	1.9L DCI		JCT0156		8200470129		R/L	внешний
Renault	Logan, SW (LS, KS) 1.4			K7J710		1.4L	04-01-07	JCA0083		6001548102/ 8200444438		L	Вал приямой
Renault	Logan, SW (LS, KS) 1.4			K7J710		1.4L	04-01-07	JCA0084		6001548103/ 8200448373		R	Вал приямой
Renault	Logan, SW (LS, KS) 1.6			K7M710		1.6L	04-01-07	JCA0083		6001548102/ 8200444438		L	Вал приямой
Renault	Logan, SW (LS, KS) 1.6			K7M710		1.6L	04-01-07	JCA0084		6001548103/ 8200448373		R	Вал приямой
Renault	Megane I	BA, BA1U	да	F9Q744	Diesel	1.9L DTI	01-	JCT0107A		8200236110		R/L	внешний
Renault	Megane I	BABA05, BA1F	да	F9Q732/ 733	Diesel	1.9L DCI	01-	JCT0107A		8200535798		R/L	внешний
Renault	Megane I	BABA05, BA1F	да	F9Q732/ 733	Diesel	1.9L DCI	01-	JCT0107A		8200535800		R/L	внешний
Renault	Megane I (Coach)	DADA0H	да	F7R710/ 714		2.0L	96-	JCA0135A		7700111914		R/L	внешний
Renault	Megane II	BM0, CM0	да	K4J732		1.4L	03-	JCT0155A		8200264668		R/L	внешний
Renault	Megane II	BM0, CM0	да	K4J730		1.4L	02-	JCT0155A		8200356803		R/L	внешний
Renault	Megane II	BM0, CM0	да	K4M762/ 788		1.6L	06-09	JCT0155A		8200358163		R/L	внешний
Renault	Megane II	BM0, CM0	да	K4M760/ 761		1.6L	02-	JCT0155A		8200432514		R/L	внешний
Renault	Megane II	BM0, CM0	да	K9K702/ 710/ 722	Diesel	1.5L	02-	JCT0155A		8200511122		R/L	внешний
Renault	Megane II	BM0, CM0	да	K9K724	Diesel	1.5L	05-	JCT0155A		8200613827		R/L	внешний
Renault	Megane II	BM0, CM0	да	K9K728/ 729	Diesel	1.5L	03-08	JCT0155A		8200623794		R/L	внешний
Renault	Megane II	BM0, CM0	да	K9K764/ 732	Diesel	1.5L	05-08	JCT0155A		8200690053		R/L	внешний
Renault	Megane I (Cabrio)	EA0, EA0H	да	F7R710/ 714		2.0L	96-	JCA0135A		7700111914		R/L	внешний
SEAT													
Seat	Altea (SP1) / Altea XL			BGU/ BSE/ BSF/ CCSA/ CMXA	Petrol	1.6L	4-04-	JCT0096		1K0407311G/1K0498099A		R/L	внешний
Seat	Cordoba	6K2/C2/6K5		ABS/ ADZ		1.8L	93-99	JCT0092		191407311B		R/L	внешний
Seat	Cordoba	6K2/C2/6K5		ADL		1.8L	93-99	JCT0092		191407311C		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.4			AEX/ AKV/ ANX/ APQ	Petrol	1.4L	96-99	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.4			AKK/ AUD	Petrol	1.4L	6-94-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.4			ANW	Petrol	1.4L	96-99	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.4 i			ABD	Petrol	1.4L	6-94-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.4 i 16v			AFH	Petrol	1.4L	96-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.6 i			AFT	Petrol	1.6L	4-96-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.6 i			IF	Petrol	1.6L	96-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.6 i			ABU	Petrol	1.6L	96-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.6 i			AEE/ ALM	Petrol	1.6L	96-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.9 D			IY	Diesel	1.9L	93-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba I (6K2/C2/6K5), Vario 1.9 SDI			AEE/ AEU	Diesel	1.9L	96-	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.0			ALD/ ANV/ AUC	Petrol	1.0L	99-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.0 16v			AST/ AVZ	Petrol	1.0L	00-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.4			AEX/ AKV/ APQ	Petrol	1.4L	99-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.4			AKK/ AUD/ ANW	Petrol	1.4L	99-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.4 16v			AFE/ AUA	Petrol	1.4L	00-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.4 16v			AFK/ ANM/ AQQ/ AUB	Petrol	1.4L	00-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.6			ALM	Petrol	1.6L	99-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.6			AEH/ AKL/ APF/ AUR	Petrol	1.6L	99-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Cordoba II (6K2/6K5), Vario 1.9 SDI			AGP/ AUM	Diesel	1.9L	99-02	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Ibiza II (6K1) 1.0			AUU	Petrol	1.0L	93-96	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний
Seat	Ibiza II (6K1) 1.0 i			AER/ ALD/ ALL/ ANV/ AUC	Petrol	1.0L	96-9-99	JCT0164	1407311K/171498099A/171498099C	191407311/191407311H/19149809		R/L	внешний

Seat	Ibiza II (6K1) 1.3 i				AAV	Petrol	1.3L	3/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.4				AEX/ AKV/ APQ	Petrol	1.4L	9/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.4				ANW	Petrol	1.4L	9/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.4				AKK/ AUD	Petrol	1.4L	9/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.4 i				ABD	Petrol	1.4L	9/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.4 i 16v				AFH	Petrol	1.4L	96-99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.6 i				AEE/ ALM	Petrol	1.6L	3/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.6 i				AFT	Petrol	1.6L	96-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.6 i				IF	Petrol	1.6L	3/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.6i				ABU	Petrol	1.6L	3/93-9/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.9 D				IY	Diesel	1.9L	93-96	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.9 SDi				AEF/ AEY	Diesel	1.9L	96-99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza II (6K1) 1.9 TDi				AFN	Diesel	1.9L	97-99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.0				ALD/ ANV/ AUC	Petrol	1.0L	99-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.4				AKK/ AUD	Petrol	1.4L	99-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.4				ANW	Petrol	1.4L	99-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.4 16v				AUA	Petrol	1.4L	00-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.4 16v				APE	Petrol	1.4L	00-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.4 16v				AFK/ ANM/ AQO/ AUB	Petrol	1.4L	99-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.6				ALM	Petrol	1.6L	99-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.6				AEH/ AKL/ APF/ AUR	Petrol	1.6L	99-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.8 T. 20v Cupra				AQX/ AYP	Petrol	1.8L	00-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Ibiza III (6K1) 1.9 SDi				AGP/ AQM	Diesel	1.9L	99-02	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.4				AEX/ AKV/ APQ	Petrol	1.4L	95-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.4				AKK/ AUD	Petrol	1.4L	95-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.4				ANW	Petrol	1.4L	95-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.4 16v				AUA	Petrol	1.4L	00-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.6 i				AEE	Petrol	1.6L	95-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.6i				IF	Petrol	1.6L	95-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.7 D				AHB	Diesel	1.7L	96-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.9 D				IY	Diesel	1.9L	95-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.9 SDi				AEY/ AYQ	Diesel	1.9L	95-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	LCV Inca (6K9) 1.9 TDi				IZ/ AHU/ ALH/ ANU	Diesel	1.9L	96-	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Toledo I (1L) 1.6 i				AFT	Petrol	1.6L	96-3/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Toledo I (1L) 1.9 D				IY	Diesel	1.9L	12/95-3/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Toledo I (1L) 1.9 SDi				AEF/ AEY	Diesel	1.9L	12/95-3/99	JCT0164	F1407311K/171498099A/171498099C/191407311/191407311H/19149809	R/L	внешний	
Seat	Altea (5P1) / Altea XL LPG				CHGA	Bi-Fuel	1.6L	09-	JCT0096	IK0407311G/IK0498099A	R/L	внешний	
Seat	Altea (5P1) / Altea XL Multifuel				CCSA	Bi-Fuel	1.6L	06-	JCT0096	IK0407311G/IK0498099A	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	113501331	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	113598101	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	171407331F	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	171407331H	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	171407331K	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	321407331	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	321407331B	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	431407331E	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	807407331	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	ZBA407331	R/L	внешний	
Seat	Cordoba I	6K2/C2/6K5			IY	Diesel	1.9L D	93-	JCN0134	ZBC407331	R/L	внешний	
Seat	Leon II (1P1) 16v				BXW/ CGGB	Petrol	1.4L	07-	JCT0096	IK0407311G/IK0498099A	R/L	внешний	
Seat	Toledo III (5P2)				BGU/ BSF/ BSE/ CCSA	Petrol	1.6L	04-	JCT0096	IK0407311G/IK0498099A	R/L	внешний	
SKODA													
Skoda	Octavia II		1U2, 1U5		AGR/ ALH	Diesel	1.9L TDi	96-01	JCN0159	191498104A	R/L	внешний	
Skoda	Superb		3U4	да	AWX/ AVF	Diesel	1.9 TDi	02-	JCT0163A	4D0598099	R/L	внешний	
Skoda	Superb I (3U4) T.			да	AWT	Petrol	1.8L	2/02-	JCT0088A	3B0498099/3B0498099A/3B0498099D/8D0407305Q	R/L	внешний	
Skoda	Fabia	6Y2, 3, 5			AQY/ AZL/ AZH	Petrol	2.0L	99-	JCT0158	6Q0498099E	R/L	внешний	
Skoda	Fabia	6Y2, 3, 5			BNM	Diesel	1.4L TDi	05-	JCT0158	6Q0498099E	R/L	внешний	
Skoda	Fabia	6Y2, 3, 5			BNV	Diesel	1.4L TDi	05-	JCT0158	6Q0498099E	R/L	внешний	
Skoda	Octavia III (1Z3, 1Z5), SW				BGU/ BSE/ BSF	Petrol	1.6L	04-	JCT0096	IK0407311G/IK0498099A	R/L	внешний	
Skoda	Octavia III (1Z3, 1Z5), SW				CCSA/ CMXA	Petrol	1.6L	08-	JCT0096	IK0407311G/IK0498099A	R/L	внешний	
Skoda	Octavia III (1Z3, 1Z5), SW FSI				BLF	Petrol	1.6L	04-	JCT0096	IK0407311G/IK0498099A	R/L	внешний	
SUBARU													
Subaru	Forester		SF5		EJ20G		2.0L	97-02	JCT0004	FU08	28021AC130	R/L	внешний
Subaru	Forester		SF5		EJ20G		2.0L	97-02	JCT0004	FU08	28021AC150	R/L	внешний
Subaru	Impreza		GC8		EJ207		2.0L	98/01	JCT0005A	FU26A44	28021AC200	R/L	внешний
Subaru	Impreza		GF8	да	4WD		2.0L	98/01	JCT0005A	FU26A44	28093AC040	R/L	внешний
Subaru	Impreza		GF8	да	4WD		2.0L	98/01	JCT0005A	FU26A44	28091AC120	R/L	внешний
Subaru	Impreza		GC8		4WD		2.0L	92-95	JCT0004	FU08	28021FA110	R/L	внешний
Subaru	Impreza		GC1				1.5L	92-95	JCT0003	FU07	28021AA541	R/L	внешний
Subaru	Impreza		GC1				1.5L	92-95	JCT0003	FU07	28021AA481	R/L	внешний
Subaru	Impreza		GC4		4WD		1.6L	92-95	JCT0003	FU07	28021AA491	R/L	внешний
Subaru	Impreza		GC4		4WD		1.6L	92-95	JCT0003	FU07	28021AA541	R/L	внешний
Subaru	Impreza		GF3				1.6L	92-95	JCT0003	FU07	28021AA541	R/L	внешний
Subaru	Impreza		GC8				2.0L	92-95	JCT0003	FU07	28021AC130	R/L	внешний
Subaru	Impreza		GFA		4WD		1.8L	92-95	JCT0003	FU07	28021AA541	R/L	внешний
Subaru	Impreza		GFA		4WD		1.8L	92-95	JCT0003	FU07	28021AA491	R/L	внешний
Subaru	Legacy		BC2				1.8L	89-91	JCT0004	FU08	28021AA501	R/L	внешний
Subaru	Legacy		BC2				1.8L	89-91	JCT0004	FU08	28021AA551	R/L	внешний
Subaru	Legacy		BC2				1.8L	89-93	JCT0004	FU08	28021AA021	R/L	внешний
Subaru	Legacy		BC2				1.8L	89-93	JCT0004	FU08	28021AA022	R/L	внешний
Subaru	Legacy		BC3		4WD		1.8L	89-93	JCT0004	FU08	28021AA511	R/L	внешний

Subaru	Legacy		BF3			EJ18	1.8L	89-93	JCT0004	FU08		28021AA511	R/L	внешний
Subaru	Legacy		BC4			EJ20	2.0L	93/04-09/93	JCT0004	FU08		28021AA551	R/L	внешний
Subaru	Legacy		BC2			EJ18	1.8L	89-93	JCT0003	FU07		28021AA130	R/L	внешний
Subaru	Legacy		BC2			EJ18	1.8L	89-93	JCT0003	FU07		28021AA131	R/L	внешний
Subaru	Legacy		BC2			EJ18	1.8L	89-93	JCT0003	FU07		28021AA132	R/L	внешний
Subaru	Legacy		BC3		4WD	EJ18	1.8L	89-93	JCT0003	FU07		28021AA541	R/L	внешний
Subaru	Legacy		BC3		4WD	EJ18	1.8L	89-93	JCT0003	FU07		28021AA011	R/L	внешний
Subaru	Legacy		BC3		4WD	EJ18	1.8L	89-93	JCT0003	FU07		28021AA013	R/L	внешний
Subaru	Legacy		BF3			EJ18	1.8L	89-93	JCT0003	FU07		28021AA491	R/L	внешний
Subaru	Legacy		BF3			EJ18	1.8L	89-93	JCT0003	FU07		28021AA541	R/L	внешний
Subaru	Legacy		BF5		4WD	EJ20	2.0L	89-93	JCT0003	FU07		28021AA130	R/L	внешний
Subaru	Legacy		BF5		4WD	EJ20	2.0L	89-93	JCT0003	FU07		28021AA131	R/L	внешний
Subaru	Legacy		BF5		4WD	EJ20	2.0L	89-93	JCT0003	FU07		28021AA132	R/L	внешний
SUZUKI														
Suzuki	Beleno Next		RM415	да		E12	1.5L	02/10	JCT0077A	SU29A42		4410154G50	R	внешний
Suzuki	Beleno Next		RM415	да		E12	1.5L	02/10	JCT0077A	SU29A42		4410254G50	L	внешний
Suzuki	Beleno Next		RM415	да		E12	1.5L	02/10	JCT0077A	SU29A42		4410155G00	R	внешний
Suzuki	Beleno Next		RM415	да		E12	1.5L	02/10	JCT0077A	SU29A42		4410255G00	L	внешний
Suzuki	Escudo / Vitara		TD11W			H20A	2.0L	94-97	JCT0040	SU11		4410177E01	R	внешний
Suzuki	ESCUDO / VITARA		TD11W			H20A	2.0L	94-97	JCT0040	SU11		4410277E01	L	внешний
Suzuki	Escudo / Vitara		TA11W			H20A	2.0L	94-97	JCT0040	SU11		4410177E10	R	внешний
Suzuki	Escudo / Vitara		TA11W			H20A	2.0L	94-97	JCT0040	SU11		4410277E01	L	внешний
Suzuki	Escudo / Vitara		TA31W			RF TBO	2.0L	94-97	JCT0040	SU11		4410177E01	R	внешний
Suzuki	Escudo / Vitara		TA31W			RF TBO	2.0L	94-97	JCT0040	SU11		4410277E01	L	внешний
Suzuki	Escudo / Vitara		TA52			J20A	2.0L	97/11	JCT0040	SU11		4410177E01	R	внешний
Suzuki	Escudo / Vitara		TA52			J20A	2.0L	97/11	JCT0040	SU11		4410277E01	L	внешний
Suzuki	Escudo / Vitara		TD31W			RF TBO	2.0L	94-97	JCT0040	SU11		4410177E01	R	внешний
Suzuki	Escudo / Vitara		TD31W			RF TBO	2.0L	94-97	JCT0040	SU11		4410277E01	L	внешний
Suzuki	Escudo / Vitara		TD52			J20A	2.0L	97/11	JCT0040	SU11		4410177E01	R	внешний
Suzuki	Escudo / Vitara		TD52			J20A	2.0L	97/11	JCT0040	SU11		4410277E01	L	внешний
Suzuki	Grand Vitara		FT, GT				2.0L	98/03	JCT0091			4410167D01	R	внешний
Suzuki	Grand Vitara		FT, GT				2.0L	98/03	JCT0091			4410267D00	L	внешний
Suzuki	Grand Vitara		ET, TA				2.0L	98/03	JCT0091			4410167D01	R	внешний
Suzuki	Grand Vitara		ET, TA				2.0L	98/03	JCT0091			4410267D00	L	внешний
Suzuki	Grand Vitara (Cabrio)		ET, TA				2.0L	98/03	JCT0091			4410167D01	R	внешний
Suzuki	Grand Vitara (Cabrio)		ET, TA				2.0L	98/03	JCT0091			4410267D00	L	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410180G10	R	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410280G40	L	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-09	JCT0041A	SU17A43		4410180G00	R	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-09	JCT0041A	SU17A43		4410280G00	L	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410180G10	R	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410280G40	L	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410180G11	R	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410180G00	R	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410280G00	L	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410279C00	L	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410279C01	L	внешний
Suzuki	Swift	да	HT51S		M13A		1.3L	00-01	JCT0041A	SU17A43		4410180G20	R	внешний
Suzuki	Swift	да	HT51S	да	4WD	M13A	1.3L	00-01	JCT0041A	SU17A43		4410280G10	L	внешний
Suzuki	Swift	да	HT51S	да	4WD	M13A	1.3L	01/04	JCT0041A	SU17A43		4410180G20	R	внешний
Suzuki	Swift	да	HT51S	да	4WD	M13A	1.3L	01/04	JCT0041A	SU17A43		4410279C00	L	внешний
Suzuki	Swift	да	HT51S	да	4WD	M13A	1.3L	00-09	JCT0041A	SU17A43		4410180G20	R	внешний
Suzuki	Swift	да	HT51S	да	4WD	M13A	1.3L	00-09	JCT0041A	SU17A43		4410280G00	L	внешний
TOYOTA														
Toyota	Avenis II (T25), SW 1.6 VVT-i	да		да		3ZZFE	1.6L	03-09	JCT0142A			4346009601	R	внешний
Toyota	Avenis II (T25), SW 1.8 16v VVTi	да		да		1ZZFE	1.8L	03-09	JCT0142A			4346009601	R	внешний
Toyota	Allion	да	AZT240	да		1AZ-FSE	2.0L	01-12	JCT0066A	TO-061A48		4341042100	R	внешний
Toyota	Allion	да	AZT240	да		1AZ-FSE	2.0L	01-12	JCT0063A	TO-061A48		4341042100	R	внешний
Toyota	Alphard	да	ANH10W	да		2AZ-FE	2.4L	02-05	JCT0066A	TO-061A48		4341028030	R	внешний
Toyota	Alphard	да	ANH15W	да	4WD	2AZ-FE	2.4L	02-05	JCT0066A	TO-061A48		4341048050	R	внешний
Toyota	Alphard	да	NH10W	да		2AZ-FE	2.4L	02-05	JCT0066A	TO-061A48		4341028030	R	внешний
Toyota	Alphard	да	NH15W	да	4WD	2AZ-FE	2.4L	02-05	JCT0066A	TO-061A48		4341048050	R	внешний
Toyota	Alphard	да	MNH15W	да	4WD	1MZ-FE	3.0L	02-05	JCT0066A	TO-061A48		4341048050	R	внешний
Toyota	Alphard	да	NH15W	да	4WD	1MZ-FE	3.0L	02-05	JCT0066A	TO-061A48		4341048050	R	внешний
Toyota	Alphard	да	ANH10W	да		2AZ-FE	2.4L	02-05	JCT0063A	TO-061A48		4341028030	R	внешний
Toyota	Alphard	да	ANH15W	да	4WD	2AZ-FE	2.4L	02-05	JCT0063A	TO-061A48		4341048050	R	внешний
Toyota	Alphard	да	NH10W	да		2AZ-FE	2.4L	02-05	JCT0063A	TO-061A48		4341028030	R	внешний
Toyota	Alphard	да	NH15W	да	4WD	2AZ-FE	2.4L	02-05	JCT0063A	TO-061A48		4341048050	R	внешний
Toyota	Alphard	да	MNH15W	да	4WD	1MZ-FE	3.0L	02-05	JCT0063A	TO-061A48		4341048050	R	внешний
Toyota	Alphard	да	NH15W	да	4WD	1MZ-FE	3.0L	02-05	JCT0063A	TO-061A48		4341048050	R	внешний
Toyota	Avenis	да	T255	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0066A	TO-061A48		4341005412	R	внешний
Toyota	Avenis	да	T255	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0066A	TO-061A48		4341021080	R	внешний
Toyota	Avenis	да	T255W	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0066A	TO-061A48		4341005412	R	внешний
Toyota	Avenis	да	T255W	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0066A	TO-061A48		4341021080	R	внешний
Toyota	Avenis	да	T255	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0063A	TO-061A48		4341005412	R	внешний
Toyota	Avenis	да	T255	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0063A	TO-061A48		4341021080	R	внешний
Toyota	Avenis	да	T255W	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0063A	TO-061A48		4341005412	R	внешний
Toyota	Avenis	да	T255W	да	4WD	1AZ-FSE	2.0L	03.09-08.12	JCT0063A	TO-061A48		4341021080	R	внешний
Toyota	Avenis II (T25), SW 1.6 VVT-i	да		да		3ZZFE	1.6L	03-09	JCT0142A			4347009A14	L	внешний
Toyota	Avenis II (T25), SW 1.8 16v VVTi	да		да		1ZZFE	1.8L	03-09	JCT0142A			4347009A14	L	внешний
Toyota	Allion	да	AZT240	да		1AZ-FSE	2.0L	01-12	JCT0066A	TO-061A48		4342020620	L	внешний

Toyota	Ipsum Picnic (europe)	ACM21W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0066A	TO-061A48	4341044040	R	внешний
Toyota	Ipsum Picnic (europe)	ACM26W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0066A	TO-061A48	4341044040	R	внешний
Toyota	Ipsum Picnic (europe)	ACM21W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0063A	TO-061A48	4341044040	R	внешний
Toyota	Ipsum Picnic (europe)	ACM26W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0063A	TO-061A48	4341044040	R	внешний
Toyota	Kluger V	ACU25W	да	4WD	2AZ-FE	2.4L	00.11-	JCT0066A	TO-061A48	4341048060	R	внешний
Toyota	Kluger V	MCU25W	да	4WD	1MZ-FE	3.0L	00.11-	JCT0066A	TO-061A48	4341048050	R	внешний
Toyota	Kluger V	ACU25W	да	4WD	2AZ-FE	2.4L	00.11-	JCT0063A	TO-061A48	4341048060	R	внешний
Toyota	Kluger V	MCU25W	да	4WD	1MZ-FE	3.0L	00.11-	JCT0063A	TO-061A48	4341048050	R	внешний
Toyota	Ipsum Picnic (europe)	ACM21W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0066A	TO-061A48	4342044040	L	внешний
Toyota	Ipsum Picnic (europe)	ACM26W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0066A	TO-061A48	4342044060	L	внешний
Toyota	Ipsum Picnic (europe)	ACM21W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0063A	TO-061A48	4342044040	L	внешний
Toyota	Ipsum Picnic (europe)	ACM26W	да	4WD	2AZ-FE	2.4L	01.05-	JCT0063A	TO-061A48	4342044060	L	внешний
Toyota	Kluger V	ACU25W	да	4WD	2AZ-FE	2.4L	00.11-	JCT0066A	TO-061A48	4342048060	L	внешний
Toyota	Kluger V	MCU25W	да	4WD	1MZ-FE	3.0L	00.11-	JCT0066A	TO-061A48	4342048060	L	внешний
Toyota	Kluger V	ACU25W	да	4WD	2AZ-FE	2.4L	00.11-	JCT0063A	TO-061A48	4342048060	L	внешний
Toyota	Kluger V	MCU25W	да	4WD	1MZ-FE	3.0L	00.11-	JCT0063A	TO-061A48	4342048060	L	внешний
Toyota	Land Cruiser	FZJ105		4WD	1HZ	4.2L	98/01	JCT0062	TO58	4340560100	R/L	внешний
Toyota	Land Cruiser	FZJ105		4WD	1HZ	4.2L	98/01	JCT0062	TO58	4340560110	R/L	внешний
Toyota	Land Cruiser	HZJ105		4WD	1FZ-FE	4.5L	98/01	JCT0062	TO58	4340560100	R/L	внешний
Toyota	Land Cruiser	HZJ105		4WD	1FZ-FE	4.5L	98/01	JCT0062	TO58	4340560110	R/L	внешний
Toyota	Land Cruiser	HZJ71/78/79			1FZ-F	4.5L	98/01	JCT0062	TO58	4340560100	R/L	внешний
Toyota	Land Cruiser	J80G	да		3F-E	4.0L	89-92	JCT0053A	TO30A48	4340560070	R/L	внешний
Toyota	Land Cruiser	J80G	да		3F-E	4.0L	89-94	JCT0053A	TO30A48	4340560070	R/L	внешний
Toyota	Land Cruiser	J81	да	4WD	1HZ-T	4.2L	89-94	JCT0053A	TO30A48	4340560070	R/L	внешний
Toyota	Land Cruiser	J80		4WD	1HD-T	4.2L	90/01	JCT0050	TO15	4430560050	R/L	внешний
Toyota	Land Cruiser	J80		4WD	1HZ	4.2L	90/01	JCT0050	TO15	4430560030	R/L	внешний
Toyota	Land Cruiser / Lexus LX470	HDJ101K		4WD	1HD-FTE	4.7L	98/01	JCT0068	TO74	4343060040	R/L	внешний
Toyota	Land Cruiser / Lexus LX470	HDJ101K		4WD	1HD-FTE	4.7L	98/01	JCT0068	TO74	4343060020	R/L	внешний
Toyota	Land Cruiser / Lexus LX470	UZJ100		4WD	2UZ-FE	4.7L	98/01	JCT0068	TO74	4343060020	R/L	внешний
Toyota	Land Cruiser / Lexus LX470	UZJ100W		4WD	2UZ-FE	4.7L	98/01	JCT0068	TO74	4343060040	R/L	внешний
Toyota	Land Cruiser / Lexus LX470	UZJ100W		4WD	2UZ-FE	4.7L	98/01	JCT0068	TO74	4343060020	R/L	внешний
Toyota	Mark II Qualis	SKV20	да		5S-FE	2.2L	97-02	JCT0048A	TO12A48	4341033020	R	внешний
Toyota	Mark II Qualis	SKV20	да		5S-FE	2.2L	97-02	JCT0048A	TO12A48	4342033020	L	внешний
Toyota	Mark II Qualis	SXV25	да	4WD	5S-FE	2.2L	97-02	JCT0048A	TO12A48	4341033110	R	внешний
Toyota	Mark II Qualis	SXV25	да	4WD	5S-FE	2.2L	97-02	JCT0048A	TO12A48	4342033110	L	внешний
Toyota	Mark II Qualis	MCV21	да		2MZ-FE	2.5L	97-02	JCT0048A	TO12A48	4341033070	R	внешний
Toyota	Mark II Qualis	MCV21	да		2MZ-FE	2.5L	97-02	JCT0048A	TO12A48	4342033070	L	внешний
Toyota	Nadia	SXN10	да		3S-FE	2.0L	98-07	JCT0045A	TO9A48	4341020581	R	внешний
Toyota	Nadia	SXN10	да		3S-FE	2.0L	98-07	JCT0045A	TO9A48	4342020421	L	внешний
Toyota	Nadia	SXN10	да		3S-FSE	2.0L	98-07	JCT0045A	TO9A48	4341020581	R	внешний
Toyota	Nadia	SXN10	да		3S-FSE	2.0L	98-07	JCT0045A	TO9A48	4342020421	L	внешний
Toyota	Nadia	SXN15	да	4WD	3S-FE	2.0L	98-07	JCT0045A	TO9A48	4341021031	R	внешний
Toyota	Nadia	SXN15	да	4WD	3S-FE	2.0L	98-07	JCT0045A	TO9A48	4342021021	L	внешний
Toyota	Noah/ Voxy	R60	да		1AZ-FSE	2.0L	05.08-07.06	JCT0066A	TO-061A48	4341028080	R	внешний
Toyota	Noah/ Voxy	R65	да	4WD	1AZ-FSE	2.0L	05.08-07.06	JCT0066A	TO-061A48	4341028090	R	внешний
Toyota	Noah/ Voxy	R70G	да		3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4341028130	R	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FAE	2.0L	07.06-	JCT0066A	TO-061A48	4341044040	R	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4341044040	R	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4341028090	R	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FAE	2.0L	07.06-	JCT0066A	TO-061A48	4341028140	R	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4341028140	R	внешний
Toyota	Noah/ Voxy	R60	да		1AZ-FSE	2.0L	05.08-07.06	JCT0063A	TO-061A48	4341028080	R	внешний
Toyota	Noah/ Voxy	R65	да	4WD	1AZ-FSE	2.0L	05.08-07.06	JCT0063A	TO-061A48	4341028090	R	внешний
Toyota	Noah/ Voxy	R70G	да		3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4341028130	R	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FAE	2.0L	07.06-	JCT0063A	TO-061A48	4341044040	R	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4341044040	R	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4341028090	R	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FAE	2.0L	07.06-	JCT0063A	TO-061A48	4341028140	R	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4341028140	R	внешний
Toyota	Noah/ Voxy	R60	да		1AZ-FSE	2.0L	05.08-07.06	JCT0066A	TO-061A48	4342028080	L	внешний
Toyota	Noah/ Voxy	R65	да	4WD	1AZ-FSE	2.0L	05.08-07.06	JCT0066A	TO-061A48	4342028120	L	внешний
Toyota	Noah/ Voxy	R70G	да		3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4342044120	L	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FAE	2.0L	07.06-	JCT0066A	TO-061A48	4342044040	L	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4342044040	L	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4342044120	L	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FAE	2.0L	07.06-	JCT0066A	TO-061A48	4342044050	L	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0066A	TO-061A48	4342044050	L	внешний
Toyota	Noah/ Voxy	R60	да		1AZ-FSE	2.0L	05.08-07.06	JCT0063A	TO-061A48	4342028080	L	внешний
Toyota	Noah/ Voxy	R65	да	4WD	1AZ-FSE	2.0L	05.08-07.06	JCT0063A	TO-061A48	4342044120	L	внешний
Toyota	Noah/ Voxy	R70G	да		3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4342044120	L	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FAE	2.0L	07.06-	JCT0063A	TO-061A48	4342044040	L	внешний
Toyota	Noah/ Voxy	R70W	да		3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4342044040	L	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4342044120	L	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FAE	2.0L	07.06-	JCT0063A	TO-061A48	4342044050	L	внешний
Toyota	Noah/ Voxy	R75G	да	4WD	3ZR-FE	2.0L	07.06-	JCT0063A	TO-061A48	4342044050	L	внешний
Toyota	Platz	NCP12	да		1NZ-FE	1.5L	99-08	JCT0054A	TO35A48	4346059045	R	внешний
Toyota	Platz	NCP16	да		2NZ-FE	1.5L	99-08	JCT0054A	TO35A48	4346059076	R	внешний
Toyota	Platz	NCP12	да		1NZ-FE	1.5L	99-08	JCT0054A	TO35A48	4347059045	L	внешний
Toyota	Platz	NCP16	да		2NZ-FE	1.5L	99-08	JCT0054A	TO35A48	4347059076	L	внешний
Toyota	Platz (NCP1#,SCP11)		да		1SZFE		08.1999 - 11.2005	JCT0058A	TO-40A48	4347059015	L	внешний
Toyota	Platz (NCP1#,SCP11)		да		1SZFE		08.1999 - 11.2005	JCT0058A	TO-40A48	4347059015	L	внешний

Toyota	Platz (NCP1#,SCP11)		да		1SZFE			08.1999 - 11.2005	JCT0058A	TO-40A48		4342052040		L	внешний
Toyota	Platz (NCP1#,SCP11)		да		1SZFE			08.1999 - 11.2005	JCT0058A	TO-40A48		4342052040		L	внешний
Toyota	Prado	J90W			1KZ-TE		3.0L	96-02	JCT0057	TO38		4343035030		R/L	внешний
Toyota	Prado	J90W			1KZ-TE		3.0L	96-02	JCT0057	TO38		4346039065		R/L	внешний
Toyota	Prado	J95W			1KZ-TE		3.0L	96-02	JCT0057	TO38		4343035030		R/L	внешний
Toyota	Prado	J95W			1KZ-TE		3.0L	96-02	JCT0057	TO38		4346039065		R/L	внешний
Toyota	Prado	J90W			5VZ-FE		3.4L	96-02	JCT0057	TO38		4343035030		R/L	внешний
Toyota	Prado	J90W			5VZ-FE		3.4L	96-02	JCT0057	TO38		4346039065		R/L	внешний
Toyota	Prado	J95W			5VZ-FE		3.4L	96-02	JCT0057	TO38		4343035030		R/L	внешний
Toyota	Prado	J95W			5VZ-FE		3.4L	96-02	JCT0057	TO38		4346039065		R/L	внешний
Toyota	Prado	J120W		4WD	3RZ-FE		2.7L	02/10	JCT0079	TO67		4343060060		R/L	внешний
Toyota	Prado	J125W		4WD	3RZ-FE		2.7L	02/10	JCT0079	TO67		4343060060		R/L	внешний
Toyota	Prado	J120W		4WD	1KD-FTV		3.0L	02/10	JCT0079	TO67		4343060060		R/L	внешний
Toyota	Prado	J121W		4WD	1KD-FTV		3.0L	02/10	JCT0079	TO67		4343060060		R/L	внешний
Toyota	Prado	J125W		4WD	1KD-FTV		3.0L	02/10	JCT0079	TO67		4343060060		R/L	внешний
Toyota	Prado	J121W		4WD	5VZ-FE		3.4L	02/10	JCT0079	TO67		4343060060		R/L	внешний
Toyota	Prado	J125W		4WD	5VZ-FE		3.4L	02/10	JCT0079	TO67		4343060060		R/L	внешний
Toyota	Premio	AZT240		да	1AZ-FSE		2.0L	01.12-	JCT0066A	TO-061A48		4341042100		R	внешний
Toyota	Premio	AZT240		да	1AZ-FSE		2.0L	01.12-	JCT0063A	TO-061A48		4341042100		R	внешний
Toyota	Premio	AZT240		да	1AZ-FSE		2.0L	01.12-	JCT0066A	TO-061A48		4342020620		L	внешний
Toyota	Premio	AZT240		да	1AZ-FSE		2.0L	01.12-	JCT0063A	TO-061A48		4342020620		L	внешний
Toyota	Raum	EXZ10		да	5E-FE		1.5L	97-05	JCT0047A	TO10A48		4341016200		R	внешний
Toyota	Raum	EXZ10		да	5E-FE		1.5L	97-05	JCT0047A	TO10A48		4342016131		L	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4341042060		R	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4342042120		L	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4342042050		L	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4342042120		L	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0066A	TO-061A48		4342042050		L	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4342042120		L	внешний
Toyota	Rav 4	ACA20W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4342042050		L	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4342042120		L	внешний
Toyota	Rav 4	ACA21W		да	4WD	1AZ-FSE	2.0L	00.05-	JCT0063A	TO-061A48		4342042050		L	внешний
Toyota	Rav 4	SXA10		да	4WD	3S-FE	2.0L	94-00	JCT0045A	TO9A48		4341042010		R	внешний
Toyota	Rav 4	SXA10		да	4WD	3S-FE	2.0L	94-00	JCT0045A	TO9A48		4342042010		L	внешний
Toyota	Rav 4	SXA10		да	4WD	3S-FE	2.0L	94-00	JCT0045A	TO9A48		4341042011		R	внешний
Toyota	Rav 4	SXA10		да	4WD	3S-FE	2.0L	94-00	JCT0045A	TO9A48		4342042011		L	внешний
Toyota	Rav 4	SXA11		да	4WD	3S-FE	2.0L	95-00	JCT0045A	TO9A48		4341042010		R	внешний
Toyota	Rav 4	SXA11		да	4WD	3S-FE	2.0L	95-00	JCT0045A	TO9A48		4342042010		L	внешний
Toyota	Rav 4	SXA11		да	4WD	3S-FE	2.0L	95-00	JCT0045A	TO9A48		4341042011		R	внешний
Toyota	Rav 4	SXA11		да	4WD	3S-FE	2.0L	95-00	JCT0045A	TO9A48		4342042011		L	внешний
Toyota	Scepter	SXV10		да	5S-FE		2.2L	92.11-96.08	JCT0052A	TO-027A48		4341060660		R	внешний
Toyota	Scepter	SXV15		да	5S-FE		2.2L	93.10-94.09	JCT0052A	TO-027A48		4341060660		R	внешний
Toyota	Scepter	SXV15W		да	5S-FE		2.2L	92.12-96.09	JCT0052A	TO-027A48		4341060660		R	внешний
Toyota	Sera	EXY10			5E-FHE		1.5L	90.03-91.01	JCT0042	TO-003		4341010150		R	внешний
Toyota	Sera	EXY10			5E-FHE		1.5L	91.01-95.12	JCT0042	TO-003		4341010220		R	внешний
Toyota	Starlet	EP71			2E-LU ELU		1.3L	84.10-89.12	JCT0042	TO-003		4341010020		R	внешний
Toyota	Starlet	EP71			2E-TELU		1.3L	84.10-89.12	JCT0042	TO-003		4341010060		R	внешний
Toyota	Starlet	EP71			2E-TELU		1.3L	86.01-89.01	JCT0042	TO-003		4341010030		R	внешний
Toyota	Starlet	EP76V			2E-LJ		1.3L	84.10-89.12	JCT0042	TO-003		4341010020		R	внешний
Toyota	Starlet	EP82			4E-F FE		1.3L	89.12-95.12	JCT0042	TO-003		4341010091		R	внешний
Toyota	Starlet	EP82			4E-F FE		1.3L	89.12-95.12	JCT0042	TO-003		4341010101		R	внешний
Toyota	Starlet	EP82			4E-FTE		1.3L	89.12-91.01	JCT0042	TO-003		4341010150		R	внешний
Toyota	Starlet	EP82			4E-FTE		1.3L	91.01-92.01	JCT0042	TO-003		4341010220		R	внешний
Toyota	Starlet	EP85		4WD	4E-F FE		1.3L	90.08-91.01	JCT0042	TO-003		4341010170		R	внешний
Toyota	Starlet	EP85		4WD	4E-F FE		1.3L	91.01-95.12	JCT0042	TO-003		4341010171		R	внешний
Toyota	Starlet	EP91			4E-FE		1.3L	96.01-99.07	JCT0042	TO-003		4341010091		R	внешний
Toyota	Starlet	EP91			4E-FE		1.3L	96.01-99.07	JCT0042	TO-003		4341010101		R	внешний
Toyota	Starlet	NP70			1N		1.5L	86.12-89.12	JCT0042	TO-003		4341010020		R	внешний
Toyota	Starlet	NP70			1N		1.5L	86.12-89.12	JCT0042	TO-003		4341010050		R	внешний
Toyota	Starlet	NP76V			1N		1.5L	86.12-89.12	JCT0042	TO-003		4341010050		R	внешний
Toyota	Starlet	NP80			1N		1.5L	89.12-95.12	JCT0042	TO-003		4341010101		R	внешний
Toyota	Starlet	NP80			1N		1.5L	89.12-95.12	JCT0042	TO-003		4341010130		R	внешний
Toyota	Starlet	NP80			1N		1.5L	89.12-95.12	JCT0042	TO-003		4341010090		R	внешний
Toyota	Starlet	NP90			1N		1.5L	96.01-99.07	JCT0042	TO-003		4341010091		R	внешний
Toyota	Starlet	NP90			1N		1.5L	96.01-99.07	JCT0042	TO-003		4341010101		R	внешний
Toyota	Starlet	NP90			1N		1.5L	96.01-99.07	JCT0042	TO-003		4341010131		R	внешний
Toyota	Scepter	SXV10		да	5S-FE		2.2L	92.11-96.08	JCT0052A	TO-027A48		4342006060		L	внешний
Toyota	Scepter	SXV15		да	5S-FE		2.2L	93.10-94.09	JCT0052A	TO-027A48		4342006060		L	внешний
Toyota	Scepter	SXV15W		да	5S-FE		2.2L	92.12-96.09	JCT0052A	TO-027A48		4342006060		L	внешний
Toyota	Sera	EXY10			5E-FHE		1.5L	90.03-91.01	JCT0042	TO-003		4342010150		L	внешний
Toyota	Sera	EXY10			5E-FHE		1.5L	91.01-95.12	JCT0042	TO-003		4342010151		L	внешний
Toyota	Starlet	EP71			2E-LU ELU		1.3L	84.10-89.12	JCT0042	TO-003		4342010020		L	внешний
Toyota	Starlet	EP71			2E-TELU		1.3L	84.10-89.10	JCT0042	TO-003		4342010060		L	внешний
Toyota	Starlet	EP71			2E-TELU		1.3L	86.01-89.01	JCT0042	TO-003		4342010030		L	внешний

Volkswagen	Jetta II GTI	19E, 1G2			EV/ GZ/ PB	1.8L	84-10	JCN0160		357498103	R/L	внешний
Volkswagen	Jetta II GTI	19E, 1G2			PL	1.8L	86-10	JCN0160		357498103A	R/L	внешний
Volkswagen	LCV CADDY II	9K9			AHU/ ALE/ ALH	Diesel	1.9L TDi	96-	JCN0159	321498103C	R/L	внешний
Volkswagen	LCV Caddy III (2KA, KB) 16v				BCA	Petrol	1.4L	04-	JCT0096	1K0407311G/1K0498099A	R/L	внешний
Volkswagen	LCV Multivan V 4motion	7HM			AXE/ BPC	Diesel	2.5L TDi	04-	JCN0162	7H0407271AH	R/L	внешний
Volkswagen	LCV Multivan V 4motion	7HM			AXD/ BNZ	Diesel	2.5L TDi	04-	JCN0162	7H0498103C	R/L	внешний
Volkswagen	LCV Transporter V 4motion	7HA/B/H/J, JD/E/L			AXE/ BPC	Diesel	2.5L TDi	03-	JCN0162	7H0407271AH	R/L	внешний
Volkswagen	LCV Transporter V 4motion	7HA/B/H/J, JD/E/L			AXD/ BNZ	Diesel	2.5L TDi	03-	JCN0162	7H0498103C	R/L	внешний
Volkswagen	Passat III	3A2, 3A5, 351			AEP		2.0L	95-96	JCN0160	357498103B	R/L	внешний
Volkswagen	Passat III Variant	3A2, 3A5, 351			IZ/ AHU	Diesel	1.9L TDi	93-97	JCN0159	357498104	R/L	внешний
Volkswagen	Passat III Variant G60 Syncro	3A2, 3A5, 351			IH/PG		1.8L	88-97	JCN0134	321407331B	R/L	внешний
Volkswagen	Passat III Variant G60 Syncro	3A2, 3A5, 351			IH/PG		1.8L	88-97	JCN0134	431407331E	R/L	внешний
Volkswagen	Passat III Variant G60 Syncro	3A2, 3A5, 351			IH/PG		1.8L	88-97	JCN0134	807407331	R/L	внешний
Volkswagen	Passat III Variant G60 Syncro	3A2, 3A5, 351			IH/PG		1.8L	88-97	JCN0134	ZBA407331	R/L	внешний
Volkswagen	Passat III Variant G60 Syncro	3A2, 3A5, 351			IH/PG		1.8L	88-97	JCN0134	ZBC407331	R/L	внешний
Volkswagen	Passat IV Variant	3B2, 3B5			ADR/ APT/ ARG		1.8L	96-	JCN0110	443407331D	R/L	внешний
Volkswagen	Passat Variant	3B3, 3B6	да		BDG	Diesel	2.5L TDi	03-05	JCT0163A	8D0407305J	R/L	внешний
Volkswagen	Passat Variant	3B3, 3B6	да		BDG	Diesel	2.5L TDi	03-05	JCT0163A	4D0498099	R/L	внешний
Volkswagen	Passat Variant	3B3, 3B6	да		BDG	Diesel	2.5L TDi	03-05	JCT0163A	4D0598099	R/L	внешний
Volkswagen	Passat Variant	3B3, 3B6	да		BDG	Diesel	2.5L TDi	03-05	JCT0163A	8D0407305J	R/L	внешний
Volkswagen	Polo III-IV Classic	6KV2			AEE/ ALM		1.6L	95-01	JCN0160		R/L	внешний
Volkswagen	Polo III-IV Classic	6KV2			AEH/ AKL/ APF/ AUR		1.6L	95-01	JCN0159		R/L	внешний
Volkswagen	Polo III-IV Classic	6KV2			AFT		1.6L	95-99	JCN0159		R/L	внешний
Volkswagen	Polo Variant	6KV5			AEH/ AKL/ APF/ AUR		1.6L	99-01	JCT0092	357498099D	R/L	внешний
Volkswagen	Touran (1T1, 1T2)				BGU	Petrol	1.6L	03-	JCT0096	1K0407311G/1K0498099A	R/L	внешний
Volkswagen	Touran (1T1, 1T2)				BSE/ BSF	Petrol	1.6L	03-	JCT0096	1K0407311G/1K0498099A	R/L	внешний
Volkswagen	Touran (1T1, 1T2) FSI				BAG/ BLF/ BLP	Petrol	1.6L	03-	JCT0096	1K0407311G/1K0498099A	R/L	внешний
Volkswagen	Transporter III				DF		1.9L	82-92	JCN0100	211598101	R/L	внешний
Volkswagen	Transporter III				CT		1.6L	79-82	JCN0100	212501331	R/L	внешний
Volkswagen	Transporter III				CT		1.6L	79-82	JCN0100	251501331	R/L	внешний
Volkswagen	Transporter III				CT		1.6L	79-82	JCN0100	251598101	R/L	внешний
Volkswagen	Vento	IH2			AHU/ ALE	Diesel	1.9L TDi	93-98	JCN0160		R/L	внешний
Volkswagen	Vento	IH2			IZ	Diesel	1.9L TDi	93-98	JCN0160		R/L	внешний
Volkswagen	Vento	IH2			AFN	Diesel	1.9L TDi	96-98	JCN0160		R/L	внешний
Volkswagen	Vento	IH2			AAZ	Diesel	1.9 TD	91-98	JCN0159		R/L	внешний
VOLVO												
Volvo	S401 / V40	VW, VS	да		B4204S		2.0L	95-04	JCT0116A	30871328	R/L	внешний
Volvo	S401 / V41	VW, VS	да		B4204S		2.0L	95-99	JCT0116A	30870499	R/L	внешний
Volvo	S401 / V41	VW, VS	да		B4164S		1.6L	95-99	JCT0116A	30871328	R/L	внешний
Volvo	S401 / V41	VW, VS	да		B4164S2		1.6L	99-03	JCT0116A	30870499	R/L	внешний
Volvo	S401 / V41	VW, VS	да		B4184S/ S3		1.6L	95-99	JCT0116A	30871328	R/L	внешний
Volvo	S401 / V41	VW, VS	да		B4184S2/ S9/ SJ		1.8L i	99-04	JCT0116A	30870499	R/L	внешний
Volvo	S401 / V41	VW, VS	да		B4184SM		1.8L i	98-04	JCT0116A	30871328	R/L	внешний
Volvo	S401 / V41	VW, VS	да		D4192T	Diesel	1.9L	95-	JCT0116A	30870499	R/L	внешний
Volvo	S401 / V41	VW, VS	да		D4192T2	Diesel	1.9L	99-	JCT0116A	30871328	R/L	внешний
Volvo	S401 / V41	VW, VS	да		D4192T4	Diesel	1.9L	00-03	JCT0116A	30870499	R/L	внешний
Volvo	S60		да		D5244T2		2.4L	01-	JCT0125A	8602577	R/L	внешний
Volvo	S60		да						JCT0125A	8603794	R/L	внешний
Volvo	S60		да						JCT0125A	9463378	R/L	внешний
Volvo	S60 I		да		D5244T5		2.5L	01-	JCT0125A	36000519	R/L	внешний